



Where Automation Connects.



**inRAX<sup>®</sup>**

**MV56E-MNET /  
MNETXT**

**ControlLogix Platform**

**Modbus TCP/IP Interface Module**

April 23, 2014

**USER MANUAL**

## **Your Feedback Please**

We always want you to feel that you made the right decision to use our products. If you have suggestions, comments, compliments or complaints about our products, documentation, or support, please write or call us.

## **How to Contact Us**

### **ProSoft Technology**

5201 Truxtun Ave., 3rd Floor  
Bakersfield, CA 93309  
+1 (661) 716-5100  
+1 (661) 716-5101 (Fax)  
[www.prosoft-technology.com](http://www.prosoft-technology.com)  
[support@prosoft-technology.com](mailto:support@prosoft-technology.com)

**Copyright © 2014 ProSoft Technology, Inc., All rights reserved.**

MVI56E-MNET / MNETXT User Manual

April 23, 2014

ProSoft Technology<sup>®</sup>, ProLinX<sup>®</sup>, inRAX<sup>®</sup>, ProTalk<sup>®</sup>, and RadioLinX<sup>®</sup> are Registered Trademarks of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

## **ProSoft Technology<sup>®</sup> Product Documentation**

In an effort to conserve paper, ProSoft Technology no longer includes printed manuals with our product shipments. User Manuals, Datasheets, Sample Ladder Files, and Configuration Files are provided on the enclosed DVD, and are available at no charge from our web site: [www.prosoft-technology.com](http://www.prosoft-technology.com)

## Important Safety Information

### North America Warnings

- A** Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.
- B** Warning - Explosion Hazard - When in Hazardous Locations, turn off power before replacing or rewiring modules.
- C** Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be nonhazardous.
- D** Suitable for use in Class I, Division 2 Groups A, B, C, and D, Hazardous Locations or Non-Hazardous Locations.

### ATEX/IECEx Warnings and Conditions of Safe Usage:

Power, Input, and Output (I/O) wiring must be in accordance with the authority having jurisdiction

- A** Warning - Explosion Hazard - When in hazardous locations, turn off power before replacing or wiring modules.
- B** Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- C** These products are intended to be mounted in an ATEX/IECEx Certified, tool-secured, IP54 enclosure. The devices shall provide external means to prevent the rated voltage being exceeded by transient disturbances of more than 40%. This device must be used only with ATEX certified backplanes.
- D** Before operating the reset switch, be sure the area is known to be non-hazardous.

<Ex>

II 3 G

Ex nA IIC T4 Gc

0°C ≤ Ta ≤ 60°C

-25°C ≤ Ta ≤ 70°C (XT models only)

II – Equipment intended for above ground use (not for use in mines).

3 – Category 3 equipment, investigated for normal operation only.

G – Equipment protected against explosive gasses. <cULus>

E183151

Class I, DIV 2, groups A,B,C,D

T5 for all models

0°C to +60°C

-25°C to +70°C (XT models only)

### Hardware Ratings

- Backplane Current Load: 800 mA @ 5 VDC; 3 mA @ 24 VDC
- Operating Temperature:
  - For standard MVI56E modules: 0°C to 60°C (32°F to 140°F)
  - For MVI56E XT (conformal coated): -25°C to 70°C (-13°F to 158°F)
- Storage Temperature: -40°C to 85°C (-40°F to 185°F)
- Shock: 30 g operational; 50 g non-operational; Vibration: 5 g from 10 to 150 Hz
- Relative Humidity: 5% to 95% (without condensation)
- All phase conductor sizes must be at least 1.3 mm (squared) and all earth ground conductors must be at least 4mm (squared).
- MVI56E XT module comes with conformal coating installed.

## Agency Approvals and Certifications

Agency
RoHS
ATEX
CSA
CE
CSA CB Safety
cULus
GOST-R
Lloyds



## Battery Life Advisory

**Note:** Modules manufactured after April 1<sup>st</sup>, 2011 do not contain a battery. For modules manufactured before that date the following applies:

The MVI56E modules use a rechargeable Lithium Vanadium Pentoxide battery to backup the real-time clock and CMOS. The battery should last for the life of the module. The module must be powered for approximately twenty hours before the battery becomes fully charged. After it is fully charged, the battery provides backup power for the CMOS setup and the real-time clock for approximately 21 days. When the battery is fully discharged, the module will revert to the default BIOS and clock settings.

**Note:** The battery is not user replaceable.

# Contents

Your Feedback Please .....	2
How to Contact Us .....	2
ProSoft Technology® Product Documentation .....	2
Warnings .....	3
Markings .....	3
Battery Life Advisory .....	4

## Guide to the MVI56E-MNET User Manual 9

### 1 Start Here 11

1.1	What's New? .....	12
1.2	System Requirements .....	13
1.3	Package Contents .....	14
1.4	Setting Jumpers .....	15
1.5	Installing the Module in the Rack .....	16
1.6	Importing the Sample Add-On Instruction .....	18
1.7	Creating a New RSLogix 5000 Project .....	19
1.7.1	Creating the Module .....	20
1.7.2	Importing the Add-On Instruction .....	22
1.8	Connecting Your PC to the ControlLogix Processor .....	32
1.9	Downloading the Sample Program to the Processor .....	33

### 2 Configuring the MVI56E-MNET Module 35

2.1	Installing ProSoft Configuration Builder .....	35
2.2	Using ProSoft Configuration Builder Software .....	36
2.2.1	Upgrading from MVI56-MNET in ProSoft Configuration Builder .....	36
2.2.2	Setting Up the Project .....	38
2.2.3	Setting Module Parameters .....	40
2.2.4	Module .....	42
2.2.5	MNET Client x .....	44
2.2.6	MNET Client x Commands .....	47
2.2.7	MNET Servers .....	54
2.2.8	Static ARP Table .....	57
2.2.9	Ethernet Configuration .....	58
2.3	Connecting Your PC to the Module .....	59
2.3.1	Setting Up a Temporary IP Address .....	60
2.4	Downloading the Project to the Module .....	63
2.4.1	Using CIPconnect to Connect to the Module .....	64
2.4.2	Using RSWho to Connect to the Module .....	73

### 3 Ladder Logic 75

3.1	Controller Tags .....	76
3.1.1	MVI56(E)-MNET Controller Tags .....	76
3.2	User-Defined Data Types (UDTs) .....	78
3.2.1	MVI56(E)-MNET User-Defined Data Types .....	78

3.3	Using Controller Tags .....	79
3.4	Controller Tag Overview .....	80
3.4.1	MNET.DATA .....	80
3.4.2	MNET.STATUS.....	83
3.4.3	MNET.CONTROL .....	84
3.4.4	MNET.UTIL .....	85
<b>4</b>	<b>Diagnostics and Troubleshooting</b>	<b>87</b>
4.1	LED Status Indicators .....	88
4.1.1	Scrolling LED Status Indicators .....	88
4.1.2	Ethernet LED Indicators.....	89
4.1.3	Non-Scrolling LED Status Indicators .....	90
4.1.4	Troubleshooting .....	91
4.1.5	Clearing a Fault Condition .....	91
4.2	Using the Diagnostics Menu in ProSoft Configuration Builder .....	92
4.2.1	Connecting to the Module's Web Page .....	95
4.2.2	The Diagnostics Menu .....	96
4.2.3	Monitoring Module Information .....	96
4.2.4	Monitoring Backplane Information .....	97
4.2.5	Monitoring MNET Client Information.....	98
4.2.6	Monitoring MNET Server Information .....	99
4.2.7	Monitoring Database Information.....	100
4.3	Reading Status Data from the Module .....	101
4.3.1	Status Data Definition .....	102
4.3.2	Configuration Error Word.....	104
4.3.3	Client Command Errors .....	105
<b>5</b>	<b>Reference</b>	<b>107</b>
5.1	Product Specifications .....	107
5.1.1	General Specifications .....	108
5.1.2	Modbus TCP/IP Specifications .....	108
5.1.3	Hardware Specifications .....	109
5.2	Backplane Data Transfer .....	110
5.2.1	Normal Data Transfer Blocks.....	113
5.2.2	Special Function Blocks.....	119
5.3	Data Flow between the MVI56E-MNET Module and ControlLogix Processor .....	131
5.3.1	Server Driver .....	132
5.3.2	Client Driver .....	134
5.4	Ethernet Cable Specifications.....	136
5.4.1	Ethernet Cable Configuration .....	136
5.4.2	Ethernet Performance.....	137
5.5	Modbus Protocol Specification .....	138
5.5.1	About the MODBUS TCP/IP Protocol.....	138
5.5.2	Read Coil Status (Function Code 01) .....	139
5.5.3	Read Input Status (Function Code 02) .....	140
5.5.4	Read Holding Registers (Function Code 03) .....	141
5.5.5	Read Input Registers (Function Code 04) .....	142
5.5.6	Force Single Coil (Function Code 05) .....	143
5.5.7	Preset Single Register (Function Code 06) .....	144
5.5.8	Read Exception Status(Function Code 7) .....	144
5.5.9	Diagnostics (Function Code 08) .....	145

5.5.10	Force Multiple Coils (Function Code 15).....	147
5.5.11	Preset Multiple Registers (Function Code 16) .....	148
5.5.12	Modbus Exception Responses.....	149
5.6	Using the Optional Add-On Instruction Rung Import.....	151
5.6.1	Before You Begin .....	151
5.6.2	Overview.....	151
5.6.3	Installing the Rung Import with Optional Add-On Instruction .....	152
5.6.4	Reading the Ethernet Settings from the Module .....	156
5.6.5	Writing the Ethernet Settings to the Module.....	157
5.6.6	Reading the Clock Value from the Module.....	158
5.6.7	Writing the Clock Value to the Module .....	159
5.7	Adding the Module to an Existing Project .....	160
5.8	Using the Sample Program .....	163
5.8.1	Opening the Sample Program in RSLogix .....	163
5.8.2	Choosing the Controller Type .....	165
5.8.3	Selecting the Slot Number for the Module .....	166
5.8.4	Downloading the Sample Program to the Processor .....	167
5.8.5	Adding the Sample Ladder to an Existing Application .....	168
<b>6</b>	<b>Support, Service &amp; Warranty</b>	<b>169</b>
	Contacting Technical Support.....	169
6.1	Return Material Authorization (RMA) Policies and Conditions.....	171
6.1.1	Returning Any Product .....	171
6.1.2	Returning Units Under Warranty .....	172
6.1.3	Returning Units Out of Warranty .....	172
6.2	LIMITED WARRANTY.....	173
6.2.1	What Is Covered By This Warranty .....	173
6.2.2	What Is Not Covered By This Warranty .....	174
6.2.3	Disclaimer Regarding High Risk Activities .....	174
6.2.4	Intellectual Property Indemnity.....	175
6.2.5	Disclaimer of all Other Warranties .....	175
6.2.6	Limitation of Remedies ** .....	176
6.2.7	Time Limit for Bringing Suit .....	176
6.2.8	No Other Warranties .....	176
6.2.9	Allocation of Risks .....	176
6.2.10	Controlling Law and Severability .....	177
	<b>Index</b>	<b>179</b>





## Guide to the MVI56E-MNET User Manual

Function		Section to Read	Details
Introduction (Must Do)	→	Start Here (page 11)	This section introduces the customer to the module. Included are: package contents, system requirements, hardware installation, and basic configuration.
Diagnostic and Troubleshooting	→	Diagnostics and Troubleshooting (page 87)	This section describes Diagnostic and Troubleshooting procedures.
Reference  Product Specifications  Functional Overview	→	Reference (page 107)  Product Specifications (page 107)  Functional Overview	These sections contain general references associated with this product, Specifications, and the Functional Overview.
Support, Service, and Warranty  Index	→	Support, Service and Warranty (page 169)  Index	This section contains Support, Service and Warranty information.  Index of chapters.



# 1 Start Here

*In This Chapter*

- ❖ What's New? ..... 12
- ❖ System Requirements ..... 13
- ❖ Package Contents ..... 14
- ❖ Setting Jumpers ..... 15
- ❖ Installing the Module in the Rack..... 16
- ❖ Importing the Sample Add-On Instruction..... 18
- ❖ Creating a New RSLogix 5000 Project ..... 19
- ❖ Connecting Your PC to the ControlLogix Processor..... 32
- ❖ Downloading the Sample Program to the Processor ..... 33

To get the most benefit from this User Manual, you should have the following skills:

- **Rockwell Automation® RSLogix™ software:** launch the program, configure ladder logic, and transfer the ladder logic to the processor
- **Microsoft Windows:** install and launch programs, execute menu commands, navigate dialog boxes, and enter data
- **Hardware installation and wiring:** install the module, and safely connect Modbus TCP/IP and ControlLogix devices to a power source and to the MVI56E-MNET module's application port(s)


## 1.1 What's New?

MVI56E products are **backward compatible** with existing MVI56 products, ladder logic, and module configuration files already in use. Easily swap and upgrade products while benefiting from an array of new features designed to improve interoperability and enhance ease of use.

- **ProSoft Configuration Builder (PCB):** New Windows software for diagnostics, connecting via the module's Ethernet port or CIPconnect®, to upload/download module configuration information and access troubleshooting features and functions.
- **ProSoft Discovery Service (PDS):** Utility software to find and display a list of MVI56E modules on the network and to temporarily change an IP address to connect with a module's web page.
- **CIPconnect-enabled:** Allows PC-to-module configuration and diagnostics from the Ethernet network through a ControlLogix 1756-ENBT EtherNet/IP™ module.
- **Personality Module:** An industrial compact flash memory card storing the module's complete configuration and Ethernet settings, allowing quick and easy replacement.
- **LED Scrolling Diagnostic Display:** 4-character, alphanumeric display, providing standard English messages for status and alarm data, and for processor and network communication status.
- **XT series for Extreme Environments:** The MVI56E-MNETXT is part of the new XT series, designed to work at extreme temperatures and in harsh or caustic environments. XT series modules operate over a wider temperature range than the standard MVI56E series. The XT series also comes with conformal coating to protect module components from corrosive environmental elements.

## 1.2 System Requirements

The MVI56E-MNET module requires the following minimum hardware and software components:

- Rockwell Automation ControlLogix<sup>®</sup> processor (firmware version 10 or higher), with compatible power supply, and one free slot in the rack for the MVI56E-MNET module. The module requires 800 mA of available 5 VDC power and 3 mA of available 24 VDC power.
- 
- Rockwell Automation RSLogix 5000 programming software
  - Version 16 or higher required for Add-On Instruction
  - Version 15 or lower must use Sample Ladder, available from [www.prosoft-technology.com](http://www.prosoft-technology.com)
- Rockwell Automation RSLinx<sup>®</sup> communication software version 2.51 or higher
- ProSoft Configuration Builder (PCB) (included)
- ProSoft Discovery Service (PDS) (included in PCB)
- Pentium<sup>®</sup> II 450 MHz minimum. Pentium III 733 MHz (or better) recommended
- Supported operating systems:
  - Microsoft Windows<sup>®</sup> Vista
  - Microsoft Windows XP Professional with Service Pack 1 or 2
  - Microsoft Windows 2000 Professional with Service Pack 1, 2, or 3
  - Microsoft Windows Server 2003
- 128 Mbytes of RAM minimum, 256 Mbytes of RAM recommended
- 100 Mbytes of free hard disk space (or more based on application requirements)
- 256-color VGA graphics adapter, 800 x 600 minimum resolution (True Color 1024 × 768 recommended)
- DVD drive

**Note:** The Hardware and Operating System requirements in this list are the minimum recommended to install and run software provided by ProSoft Technology<sup>®</sup>. Other third party applications may have different minimum requirements. Refer to the documentation for any third party applications for system requirements.

**Note:** You can install the module in a local or remote rack. For remote rack installation, the module requires EtherNet/IP or ControlNet communication with the processor.

### 1.3 Package Contents

The following components are included with your MVI56E-MNET module, and are all required for installation and configuration.

**Important:** Before beginning the installation, please verify that all of the following items are present.


Qty.	Part Name	Part Number	Part Description
1	MVI56E-MNET / MNETXT Module	MVI56E-MNET / MNETXT	Modbus TCP/IP Interface Module
1	Cable	RL-CBL025	5-foot Ethernet Straight-Through Cable (Gray)
1	ProSoft Solutions DVD	DVD-001	Contains configuration tools for the MVI56E-MNET module

If any of these components are missing, please contact ProSoft Technology Support for replacement parts.

## 1.4 Setting Jumpers

The Setup Jumper acts as "write protection" for the module's flash memory. In "write protected" mode, the Setup pins are not connected, and the module's firmware cannot be overwritten. Do not jumper the Setup pins together unless you are directed to do so by ProSoft Technical Support.

The following illustration shows the MVI56E-MNET jumper configuration.



**Note:** If you are installing the module in a remote rack, you may prefer to leave the Setup pins jumpered. That way, you can update the module's firmware without requiring physical access to the module.

## 1.5 Installing the Module in the Rack

If you have not already installed and configured your ControlLogix processor and power supply, please do so before installing the MVI56E-MNET module. Refer to your Rockwell Automation product documentation for installation instructions.

**Warning:** You must follow all safety instructions when installing this or any other electronic devices. Failure to follow safety procedures could result in damage to hardware or data, or even serious injury or death to personnel. Refer to the documentation for each device you plan to connect to verify that suitable safety procedures are in place before installing or servicing the device.

After you have checked the placement of the jumpers, insert the MVI56E-MNET into the ControlLogix chassis. Use the same technique recommended by Rockwell Automation to remove and install ControlLogix modules.

You can install or remove ControlLogix system components while chassis power is applied and the system is operating. However, please note the following warning.

**Warning:** When you insert or remove the module while backplane power is on, an electrical arc can occur. An electrical arc can cause personal injury or property damage by sending an erroneous signal to your system's actuators. This can cause unintended machine motion or loss of process control. Electrical arcs may also cause an explosion when they happen in a hazardous environment. Verify that power is removed or the area is non-hazardous before proceeding. Repeated electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance that can affect module operation.

- 1 Align the module with the top and bottom guides, and then slide it into the rack until the module is firmly against the backplane connector.



- 2 With a firm, steady push, snap the module into place.
- 3 Check that the holding clips on the top and bottom of the module are securely in the locking holes of the rack.



- 4 Make a note of the slot location. You must identify the slot in which the module is installed in order for the sample program to work correctly. Slot numbers are identified on the green circuit board (backplane) of the ControlLogix rack.
- 5 Turn power ON.

**Note:** If you insert the module improperly, the system may stop working or may behave unpredictably.

**Note:** When using the MVI56EMNETXT, you must use the 1756-A5XT or 1756-A7LXT chassis. In these chassis, modules are spaced further apart than in standard ControlLogix chassis. Blank spacers are inserted between active modules.

## 1.6 Importing the Sample Add-On Instruction

**Note:** This section only applies if your processor is using RSLogix 5000 version 16 or higher. If you have an earlier version, please see Using the Sample Program (page 163).

### Before You Begin


Two Add-On Instructions are provided for the MVI56E-MNET module. The first is required for setting up the module; the second is optional.

Copy the files from the *ProSoft Solutions DVD*, or download them from [www.prosoft-technology.com](http://www.prosoft-technology.com). Save them to a convenient location in your PC, such as *Desktop* or *My Documents*.


File Name	Description
MVI56EMNET_AddOn_Rung_v1_4.L5X	L5X file containing Add-On Instruction, user defined data types, controller tags and ladder logic required to configure the MVI56E-MNET module
MVI56EMNET_Optional_AddOn_Rung_v1_0.L5X	Optional L5X file containing additional Add-On Instruction with logic for changing Ethernet configuration and clock settings.

## 1.7 Creating a New RSLogix 5000 Project

- 1 Open the **FILE** menu, and then choose **NEW**.




- 2 Select your ControlLogix controller model.
- 3 Select **REVISION 16**.
- 4 Enter a name for your controller, such as *My\_Controller*.
- 5 Select your ControlLogix chassis type.
- 6 Select **SLOT 0** for the controller.




### 1.7.1 Creating the Module

#### 1 Add the MVI56E-MNET module to the project.

In the *Controller Organization* window, select **I/O CONFIGURATION** and click the right mouse button to open a shortcut menu. On the shortcut menu, choose **NEW MODULE...**



This action opens the *Select Module* dialog box.



#### 2 Select the **1756-MODULE (GENERIC 1756 MODULE)** from the list and click **OK**.


This action opens the *New Module* dialog box.

#### 3 In the *New Module* dialog box, enter the following values.


Parameter	Value
Name	Enter a module identification string. Example: <b>MNET</b> .
Description	Enter a description for the module. Example: <b>MODBUS TCP/IP INTERFACE MODULE</b>
Comm Format	Select <b>DATA-INT</b> .
Slot	Enter the slot number in the rack where the MVI56E-MNET module is located.
Input Assembly Instance	<b>1</b>
Input Size	<b>250</b>
Output Assembly Instance	<b>2</b>
Output Size	<b>248</b>
Configuration Assembly Instance	<b>4</b>
Configuration Size	<b>0</b>

**Important:** You must select the **COMM FORMAT** as **DATA - INT** in the dialog box, otherwise the module will not communicate over the backplane of the ControlLogix rack.

- 4 Click **OK** to continue.
- 5 **Edit the Module Properties.** Select the **REQUESTED PACKET INTERVAL** value for scanning the I/O on the module. This value represents the minimum frequency at which the module will handle scheduled events. This value should not be set to less than 1 millisecond. The default value is 5 milliseconds. Values between 1 and 10 milliseconds should work with most applications.




- 6 **Save the module.**  
Click **OK** to close the dialog box. Notice that the module now appears in the *Controller Organization* window.




## 1.7.2 Importing the Add-On Instruction


- 1 In the *Controller Organization* window, expand the *Tasks* folder and subfolder until you reach the *MainProgram* folder.
- 2 In the *MainProgram* folder, double-click to open the **MAINROUTINE** ladder.
- 3 Select an empty rung in the new routine, and then click the right mouse button to open a shortcut menu. On the shortcut menu, choose **IMPORT RUNG**.



- 4 Navigate to the location on your PC where you saved (page 18) the Add-On Instruction (for example, *My Documents* or *Desktop*). Select the **MVI56EMNET\_AddON\_RUNG\_v1\_4.L5X** file.




This action opens the *Import Configuration* dialog box, showing the controller tags that will be created.




- 5 If you are using the module in a different slot (or remote rack), select the correct connection input and output variables that define the path to the module. If your module is located in Slot 1 of the local rack, this step is not required.

- 6 Click **OK** to confirm the import. RSLogix 5000 will indicate that the import is in progress:



When the import is completed, the new rung with the Add-On Instruction will be visible as shown in the following illustration.



The procedure has also imported new user-defined data types, data objects and the Add-On instruction for your project.




- 7 **SAVE** the application and then download the sample ladder logic into the processor.




### Adding Multiple Modules (Optional)

- 1 In the *I/O Configuration* folder, click the right mouse button to open a shortcut menu, and then choose **NEW MODULE**.




- 2 Select **1756-MODULE**.




- 3 Fill the module properties as follows:

Parameter	Value
Name	Enter a module identification string. Example: <b>MNET_2</b>
Description	Enter a description for the module. Example: <b>MODBUS TCP/IP INTERFACE MODULE</b>
Comm Format	Select <b>DATA-INT</b> .
Slot	Enter the slot number in the rack where the MVI56E-MNET module is located.
Input Assembly Instance	<b>1</b>
Input Size	<b>250</b>
Output Assembly Instance	<b>2</b>
Output Size	<b>248</b>
Configuration Assembly Instance	<b>4</b>
Configuration Size	<b>0</b>


- 4 Click **OK** to confirm. The new module is now visible:




- 5 Expand the *Tasks* folder, and then expand the *MainTask* folder.
- 6 On the *MainProgram* folder, click the right mouse button to open a shortcut menu. On the shortcut menu, choose **NEW ROUTINE**. As an alternative to creating a separate **NEW ROUTINE**, you could skip to Step 8 and import the AOI for the second module into the same routine you created for the first module.
- 7 In the *New Routine* dialog box, enter the name and description of your routine, and then click **OK**.
- 8 Select an empty rung in the new routine or an existing routine, and then click the right mouse button to open a shortcut menu. On the shortcut menu, choose **IMPORT RUNG**.





9 Select the file **MVI56EMNET\_AddOn\_RUNG\_v1\_4.L5X**.




10 The following window will be displayed showing the tags to be imported:




- 11 Associate the I/O connection variables to the correct module. The default values are **LOCAL:1:I** and **LOCAL:1:O** so these require change.



Change the default tags *MNET* and *AOI56MNET* to avoid conflict with existing tags. This procedure will append the string "\_2" as follows:



12 Click **OK** to confirm.



### Adjusting the Input and Output Array Sizes

**Note:** It is unnecessary to manually edit the *ReadData* and *WriteData* user-defined data types in the ladder logic, as these are automatically updated to match the changed array sizes from *ProSoft Configuration Builder*.

The module internal database is divided into two user-configurable areas:


- Read Data
- Write Data

The Read Data area is moved from the module to the processor, while the Write Data area is moved from the processor to the module.

The MVI56E-MNET Add-On Instruction rung is configured for 600 registers of Read Data and 600 registers of Write Data, which is sufficient for most applications. However, you can configure the sizes of these data areas to meet the needs of your application.

- 1 In *ProSoft Configuration Builder*, expand the *Module* icon in the tree view and double-click **MODULE** to open an *Edit* window. Change the **READ REGISTER COUNT** to contain the number of words for your Read Data area.

**Important:** Because the module pages data in blocks of 200 registers at a time, you should configure your user data areas in multiples of 200 registers.




- 2 To modify the *WriteData* array, follow the above steps, substituting *WriteData* for *ReadData*.

- 3** Save and download the configuration to the module (page 63) and reboot.  
Make sure that the *ReadData* and *WriteData* arrays do not overlap in the module memory. For example, if your application requires 2000 words of *WriteData* starting at register 0, then your *Read Register Start* parameter must be set to a value of 2000 or greater.


## 1.8 Connecting Your PC to the ControlLogix Processor

There are several ways to establish communication between your PC and the ControlLogix processor. The following steps show how to establish communication through the serial interface. It is not mandatory that you use the processor's serial interface. You may access the processor through whatever network interface is available on your system. Refer to your Rockwell Automation documentation for information on other connection methods.

- 1 Connect the right-angle connector end of the cable to your controller at the communications port.



- 2 Connect the straight connector end of the cable to the serial port on your computer.







## 1.9 Downloading the Sample Program to the Processor

**Note:** The key switch on the front of the ControlLogix processor must be in the REM or PROG position.

- 1 If you are not already online with the processor, open the *Communications* menu, and then choose **DOWNLOAD**. RSLogix 5000 will establish communication with the processor. You do not have to download through the processor's serial port, as shown here. You may download through any available network connection.
- 2 When communication is established, RSLogix 5000 will open a confirmation dialog box. Click the **DOWNLOAD** button to transfer the sample program to the processor.



- 3 RSLogix 5000 will compile the program and transfer it to the processor. This process may take a few minutes.
- 4 When the download is complete, RSLogix 5000 will open another confirmation dialog box. If the key switch is in the REM position, click **OK** to switch the processor from PROGRAM mode to RUN mode.



**Note:** If you receive an error message during these steps, refer to your RSLogix documentation to interpret and correct the error.



## 2 Configuring the MVI56E-MNET Module


### In This Chapter

- ❖ Installing ProSoft Configuration Builder ..... 35
- ❖ Using ProSoft Configuration Builder Software ..... 36
- ❖ Connecting Your PC to the Module ..... 59
- ❖ Downloading the Project to the Module ..... 63

### 2.1 Installing ProSoft Configuration Builder

#### To install ProSoft Configuration Builder from the DVD

- 1 Insert the *ProSoft Solutions DVD* into the DVD drive of your PC. Wait for the startup screen to appear.



- 2 On the startup screen, click **INSTALL PROSOFT CONFIGURATION BUILDER**. This action starts the installation wizard for *ProSoft Configuration Builder*.
- 3 Click **NEXT** on each page of the installation wizard. Click **FINISH** on the last page of the wizard.

## 2.2 Using ProSoft Configuration Builder Software

*ProSoft Configuration Builder (PCB)* provides a quick and easy way to manage module configuration files customized to meet your application needs. *PCB* is not only a powerful solution for new configuration files, but also allows you to import information from previously installed (known working) configurations to new projects.

**Note:** During startup and initialization, the MVI56E-MNET module receives its protocol and backplane configuration information from the installed Personality Module (Compact Flash). Use *ProSoft Configuration Builder* to configure module settings and to download changes to the Personality Module.


### 2.2.1 Upgrading from MVI56-MNET in ProSoft Configuration Builder

MVI56E-MNET modules are fully backward-compatible with MVI56-MNET modules. However, you will need to convert your MVI56-MNET configuration in *ProSoft Configuration Builder* to a form that your new MVI56E-MNET module will accept when you download it.

*ProSoft Configuration Builder* version 2.2.2 or later has an upgrade option that easily performs this conversion, while preserving all your configuration settings and any name you may have given your module.

**Important:** For this procedure, you need to have *ProSoft Configuration Builder* version 2.2.2 or later installed on your PC. You can download the latest version from [www.prosoft-technology.com](http://www.prosoft-technology.com).


- 1 In *ProSoft Configuration Builder's* tree view, click the **MODULE** icon and right-click to open a shortcut menu.




- 2 On the shortcut menu, select **CHANGE MODULE TYPE TO MVI56E-MNET**.

## 2.2.2 Setting Up the Project

To begin, start **PROSOFT CONFIGURATION BUILDER (PCB)**.




If you have used other Windows configuration tools before, you will find the screen layout familiar. *PCB's* window consists of a tree view on the left, and an information pane and a configuration pane on the right side of the window. When you first start *PCB*, the tree view consists of folders for *Default Project* and *Default Location*, with a *Default Module* in the *Default Location* folder. The following illustration shows the *PCB* window with a new project.



Your first task is to add the MVI56E-MNET module to the project.

- 1 Use the mouse to select **DEFAULT MODULE** in the tree view, and then click the right mouse button to open a shortcut menu.


- 2 On the shortcut menu, select **CHOOSE MODULE TYPE**. This action opens the *Choose Module Type* dialog box.



- 3 In the *Product Line Filter* area of the dialog box, select **MVI56E**. In the *Select Module Type* dropdown list, select **MVI56E-MNET**, and then click **OK** to save your settings and return to the *ProSoft Configuration Builder* window.

## 2.2.3 Setting Module Parameters

Notice that the contents of the information pane and the configuration pane changed when you added the MVI56E-MNET module to the project.





At this time, you may wish to rename the *Default Project* and *Default Location* folders in the tree view.

### Renaming an Object



- 1 Select the object, and then click the right mouse button to open a shortcut menu. From the shortcut menu, choose **RENAME**.
- 2 Type the name to assign to the object.
- 3 Click away from the object to save the new name.


### Configuring Module Parameters

- 1 Click on the **[+]** sign next to the module icon to expand module information.
- 2 Click on the **[+]** sign next to any  icon to view module information and configuration options.
- 3 Double-click any  icon to open an *Edit* dialog box.
- 4 To edit a parameter, select the parameter in the left pane and make your changes in the right pane.
- 5 Click **OK** to save your changes.



### Creating Optional Comment Entries

- 1 Click the **[+]** to the left of the  **Comment** icon to expand the module comments.
- 2 Double-click the  **Module Comment** icon. The *Edit - Module Comment* dialog box appears.



- 3 Enter your comment and click **OK** to save your changes.

### Printing a Configuration File

- 1 Select the module icon, and then click the right mouse button to open a shortcut menu.
- 2 On the shortcut menu, choose **VIEW CONFIGURATION**. This action opens the *View Configuration* window.
- 3 In the *View Configuration* window, open the **FILE** menu, and choose **PRINT**. This action opens the *Print* dialog box.
- 4 In the *Print* dialog box, choose the printer to use from the drop-down list, select printing options, and then click **OK**.

## 2.2.4 Module

This section of the configuration describes the database setup and module-level parameters.

### Backplane Error/Status Pointer

**1 to 4955**

This parameter sets the address in the internal database where the backplane error/status data will be placed. If you want the error/status data to be moved to the processor and placed into the *ReadData* array, the value entered should be a module memory address in the Read Data area. If the value is set to **-1**, the error/status data will not be stored in the module's internal database and will not be transferred to the processor's *ReadData* array.

Enabling the *Error/Status Pointer* is optional. The error/status data is routinely returned as part of the input image, which is continually being transferred from the module to the processor. For more information, see Normal Data Transfer Blocks (page 113).

### Read Register Start

**0 to 4999**

The *Read Register Start* parameter specifies the start of the Read Data area in module memory. Data in this area will be transferred from the module to the processor.

**Note:** Total user database memory space is limited to the first 5000 registers of module memory, addresses 0 through 4999. Therefore, the practical limit for this parameter is 4999 minus the value entered for *Read Register Count*, so that the Read Data Area does not try to extend above address 4999. Read Data and Write Data Areas must be configured to occupy separate address ranges in module memory and should not be allowed to overlap.

### Read Register Count

**0 to 5000**

The *Read Register Count* parameter specifies the size of the Read Data area of module memory and the number of registers to transfer from this area to the processor, up to a maximum of 5000 words.

**Note:** Total *Read Register Count* and *Write Register Count* cannot exceed 5000 total registers. Read Data and Write Data Areas must be configured to occupy separate address ranges in module memory and should not be allowed to overlap.

### Write Register Start

**0 to 4999**

The *Write Register Start* parameter specifies the start of the Write Data area in module memory. Data in this area will be transferred in from the processor.

**Note:** Total user database memory space is limited to the first 5000 registers of module memory, addresses 0 through 4999. Therefore, the practical limit for this parameter is 4999 minus the value entered for *Write Register Count*, so that the Write Data Area does not try to extend above address 4999. Read Data and Write Data Areas must be configured to occupy separate address ranges in module memory and should not be allowed to overlap.

### Write Register Count

**0 to 5000**

The *Write Register Count* parameter specifies the size of the Write Data area of module memory and the number of registers to transfer from the processor to this memory area, up to a maximum value of 5000 words.

**Note:** Total *Read Register Count* and *Write Register Count* cannot exceed 5000 total registers. Read Data and Write Data Areas must be configured to occupy separate address ranges in module memory and should not be allowed to overlap.

### Failure Flag Count

**0 through 65535**

This parameter specifies the number of successive transfer errors that must occur before halting communication on the application port(s). If the parameter is set to **0**, the application port(s) will continue to operate under all conditions. If the value is set larger than **0** (**1 to 65535**), communications will cease if the specified number of failures occur.

### Initialize Output Data

**0 = No, 1 = Yes**

This parameter is used to determine if the output data for the module should be initialized with values from the processor. If the value is set to **0**, the output data will be initialized to 0. If the value is set to **1**, the data will be initialized with data from the processor. Use of this option requires associated ladder logic to pass the data from the processor to the module.

### Pass-Through Mode

#### **0, 1, 2 or 3**

This parameter specifies the pass-through mode for write messages received by the MNET and MBAP server ports.

- If the parameter is set to **0**, all write messages will be placed in the module's virtual database.
- If a value of **1** is entered, write messages received will be sent to the processor as unformatted messages.
- If a value of **2** is entered, write messages received will be sent to the processor as formatted messages.
- If a value of **3** is entered, write messages received will be sent to the processor with the bytes swapped in a formatted message.

### Duplex/Speed Code

#### **0, 1, 2, 3 or 4**

This parameter allows you to cause the module to use a specific duplex and speed setting.

- Value = **1**: Half duplex, 10 MB speed
- Value = **2**: Full duplex, 10 MB speed
- Value = **3**: Half duplex, 100 MB speed
- Value = **4**: Full duplex, 100 MB speed
- Value = **0**: Auto-negotiate

Auto-negotiate is the default value for backward compatibility. This feature is not implemented in older software revisions.

## **2.2.5 MNET Client x**

This section defines general configuration for the MNET Client (Master).

### Client Error/Status Pointer

#### **1 to 4990**

This parameter sets the address in the internal database where the Client error/status data will be placed. If you want the error/status data to be moved to the processor and placed into the *ReadData* array, the value entered should be a module memory address in the Read Data area. If the value is set to **-1**, the error/status data will not be stored in the module's internal database and will not be transferred to the processor's *ReadData* array.

Enabling the *Error/Status Pointer* is optional. The error/status data is routinely returned as part of the input image, which is continually being transferred from the module to the processor. For more information, see Normal Data Transfer Blocks (page 113).

### Command Error Pointer

**-1 to 4999**

This parameter sets the address in the internal database where the Command Error List data will be placed. If you want the Command Error List data to be moved to the processor and placed into the *ReadData* array, the value entered should be a module memory address in the Read Data area. If the value is set to **-1**, the Command Error List data will not be stored in the module's internal database and will not be transferred to the processor's *ReadData* array.

### Minimum Command Delay

**0 to 65535** milliseconds

This parameter specifies the number of milliseconds to wait between the initial issuances of a command. This parameter can be used to delay all commands sent to servers to avoid "flooding" commands on the network. This parameter does not affect retries of a command as they will be issued when failure is recognized.

### Response Timeout

**0 to 65535** milliseconds

This is the time in milliseconds that a Client will wait before re-transmitting a command if no response is received from the addressed server. The value to use depends on the type of communication network used, and the expected response time of the slowest device on the network.

### Retry Count

**0 to 10**

This parameter specifies the number of times a command will be retried if it fails.

### Float Flag

**YES or NO**

This flag specifies how the Client driver will issue Function Code 3, 6, and 16 commands (read and write Holding Registers) to a remote server when it is moving 32-bit floating-point data.

If the remote server expects to receive or will send one complete 32-bit floating-point value for each count of one (1), then set this parameter to **YES**. When set to **YES**, the Client driver will send values from two consecutive 16-bit internal memory registers (32 total bits) for each count in a write command, or receive 32 bits per count from the server for read commands. Example: Count = **10**, Client driver will send 20 16-bit registers for 10 total 32-bit floating-point values.

If, however, the remote server expects to use a count of two (2) for each 32-bit floating-point value it sends or receives, or if you do not plan to use floating-point data in your application, then set this parameter to **No**, which is the default setting.

You will also need to set the *Float Start* and *Float Offset* parameters to appropriate values whenever the *Float Flag* parameter is set to **YES**.

#### *Float Start*

**0 to 65535**

Whenever the *Float Flag* parameter is set to **YES**, this parameter determines the lowest Modbus Address, used in commands to a remote server, to consider as commands to read or write floating-point data. All commands with address values greater than or equal to this value will be considered floating-point data commands. All commands with address values less than this value will be considered normal 16-bit register data commands.

This parameter is used only if the *Float Flag* is set to **YES**. For example, if a value of 7000 is entered, all commands sent with addresses of 47001 (or 407001) and above will be considered as floating-point data commands and 32 bits of data will be sent or received for each count of one in the command.

You will also need to set the *Float Offset* parameter to an appropriate value whenever the *Float Flag* parameter is set to **YES**.

#### *Float Offset*

**0 to 9999**

This parameter defines the start register for floating-point data in the internal database. This parameter is used only if the *Float Flag* is enabled. For example, if the *Float Offset* value is set to **3000** and the *Float Start* parameter is set to **7000**, data requests for register 7000 will use the internal Modbus register 3000.

#### *ARP Timeout*

**1 to 60**

This parameter specifies the number of seconds to wait for an ARP reply after a request is issued.

#### *Command Error Delay*

**0 to 300**

This parameter specifies the number of 100 millisecond intervals to turn off a command in the error list after an error is recognized for the command. If this parameter is set to **0**, there will be no delay.

### **2.2.6 MNET Client x Commands**

The *MNET Client x Commands* section of the configuration sets the Modbus TCP/IP Client command list. This command list polls Modbus TCP/IP server devices attached to the Modbus TCP/IP Client port. The module supports numerous commands. This permits the module to interface with a wide variety of Modbus TCP/IP protocol devices.

The function codes used for each command are those specified in the Modbus protocol. Each command list record has the same format. The first part of the record contains the information relating to the MVI56E-MNET communication module, and the second part contains information required to interface to the Modbus TCP/IP server device.

#### Command List Overview

In order to interface the MVI56E-MNET module with Modbus TCP/IP server devices, you must construct a command list. The commands in the list specify the server device to be addressed, the function to be performed (read or write), the data area in the device to interface with and the registers in the internal database to be associated with the device data. The Client command list supports up to 100 commands.

The command list is processed from top (command #1) to bottom. A poll interval parameter is associated with each command to specify a minimum delay time in tenths of a second between the issuances of a command. If the user specifies a value of 10 for the parameter, the command will be executed no more frequently than every 1 second.

Write commands have a special feature, as they can be set to execute only if the data in the write command changes. If the register data values in the command have not changed since the command was last issued, the command will not be executed.

If the data in the command has changed since the command was last issued, the command will be executed. Use of this feature can lighten the load on the network. To implement this feature, set the enable code for the command to **CONDITIONAL (2)**.

### Commands Supported by the Module

The format of each command in the list depends on the Modbus Function Code being executed.

The following table lists the functions supported by the module.

Function Code	Definition	Supported in Client	Supported in Server
1	Read Coil Status	X	X
2	Read Input Status	X	X
3	Read Holding Registers	X	X
4	Read Input Registers	X	X
5	Set Single Coil	X	X
6	Single Register Write	X	X
7	Read Exception Status	X	X
8	Diagnostics		X
15	Multiple Coil Write	X	X
16	Multiple Register Write	X	X
22	Mask Write 4X		X
23	Read/Write		X

Each command list record has the same general format. The first part of the record contains the information relating to the communication module and the second part contains information required to interface to the Modbus TCP/IP server device.

### Command Entry Formats


The following table shows the structure of the configuration data necessary for each of the supported commands.

1	2	3	4	5	6	7	8	9	10
Enable Code	Internal Address	Poll Interval Time	Count	Swap Code	IP Address	Serv Port	Slave Node	Function Code	Device Modbus Address
Code	Register (bit)	1/10th Seconds	Bit Count	0	IP Address	Port #	Address	Read Coil (0x)	Register
Code	Register (bit)	1/10th Seconds	Bit Count	0	IP Address	Port #	Address	Read Input (1x)	Register
Code	Register	1/10th Seconds	Word Count	Code	IP Address	Port #	Address	Read Holding Registers (4x)	Register
Code	Register	1/10th Seconds	Word Count	0	IP Address	Port #	Address	Read Input Registers (3x)	Register
Code	1 bit	1/10th Seconds	Bit Count	0	IP Address	Port #	Address	Force (Write) Single Coil (0x)	Register
Code	1 bit	1/10th Seconds	Word Count	0	IP Address	Port #	Address	Preset (Write) Single Register (4x)	Register
Code	Register (bit)	1/10th Seconds	Bit Count	0	IP Address	Port #	Address	Force (Write) Multiple Coil (0x)	Register
Code	Register	1/10th Seconds	Word Count	0	IP Address	Port #	Address	Preset (Write) Multiple Register (4x)	Register



The first part of the record is the module information, which relates to the MVI56E module, and the second part contains information required to interface to the server device.

**Command list example:**



**Enable**

**No (0), YES (1), or CONDITIONAL (2)**

This field defines whether the command is to be executed and under what conditions.

Value	Description
<b>No (0)</b>	The command is disabled and will not be executed in the normal polling sequence.
<b>YES (1)</b>	The command is executed each scan of the command list if the <i>Poll Interval</i> time is set to zero. If the <i>Poll Interval</i> time is set to a nonzero value, the command will be executed when the interval timer expires.
<b>CONDITIONAL (2)</b>	The command will execute only if the internal data associated with the command changes. This value is valid only for write commands.

### Internal Address

**0** to **65535** (for bit-level addressing)

or

**0** to **4999** (for word-level addressing)

This field specifies the database address in the module's internal database to use as the destination for data brought in by a read command or as the source for data to be sent out by a write command. The database address is interpreted as a bit address or a 16-bit word (register) address, depending on the Modbus Function Code used in the command.

- For Modbus functions 1, 2, 5, and 15, this parameter is interpreted as a bit-level address.
- For Modbus functions 3, 4, 6, and 16, this parameter is interpreted as a word-level or register-level address.

### Poll Interval

**0** to **65535**

This parameter specifies the minimum interval between issuances of a command during continuous command execution (*Enable* code of **1**). The parameter is entered in tenths of a second. Therefore, if a value of **100** is entered for a command, the command executes no more frequently than every 10 seconds.

### Reg Count

Regs: **1** to **125**

Coils: **1** to **800**

This parameter specifies the number of 16-bit registers or binary bits to be transferred by the command.

- Functions 5 and 6 ignore this field as they apply only to a single data point.
- For functions 1, 2, and 15, this parameter sets the number of bits (inputs or coils) to be transferred by the command.
- For functions 3, 4, and 16, this parameter sets the number of registers to be transferred by the command.

### Swap Code

**NONE**

**SWAP WORDS**

**SWAP WORDS & BYTES**

**SWAP BYTES**

This parameter defines if and how the order of bytes in data received or sent is to be rearranged. This option exists to allow for the fact that different manufacturers store and transmit multi-byte data in different combinations. This parameter is helpful when dealing with floating-point or other multi-byte values, as there is no one standard method of storing these data types. The parameter can be set to rearrange the byte order of data received or sent into an order more useful or convenient for other applications. The following table defines the valid *Swap Code* values and the effect they have on the byte-order of the data.

Swap Code	Description
<b>NONE</b>	No change is made in the byte ordering (1234 = 1234)
<b>SWAP WORDS</b>	The words are swapped (1234=3412)
<b>SWAP WORDS &amp; BYTES</b>	The words are swapped, then the bytes in each word are swapped (1234=4321)
<b>SWAP BYTES</b>	The bytes in each word are swapped (1234=2143)

These swap operations affect 4-byte (or 2-word) groups of data. Therefore, data swapping using these *Swap Codes* should be done only when using an even number of words, such as when 32-bit integer or floating-point data is involved.

### Node IP Address

xxx.xxx.xxx.xxx

The IP address of the device being addressed by the command.

### Service Port

**502** or other port numbers supported on a server

Use a value of **502** when addressing Modbus TCP/IP servers that are compatible with the Schneider Electric MBAP specifications (this will be most devices). If a server implementation supports another service port, enter the value here.

### Slave Address

**0** - Broadcast to all nodes

**1 to 255**

Use this parameter to specify the slave address of a remote Modbus Serial device through a Modbus Ethernet to Serial converter.

**Note:** Use the *Node IP Address* parameter (page 51) to address commands to a remote Modbus TCP/IP device.

**Note:** Most Modbus devices accept an address in the range of only 1 to 247, so check with the slave device manufacturer to see if a particular slave can use addresses 248 to 255.

If the value is set to zero, the command will be a broadcast message on the network. The Modbus protocol permits broadcast commands for **write** operations. **Do not** use node address 0 for **read** operations.

### Modbus Function

**1, 2, 3, 4, 5, 6, 15, or 16**

This parameter specifies the Modbus Function Code to be executed by the command. These function codes are defined in the Modbus protocol. The following table lists the purpose of each function supported by the module. More information on the protocol is available from [www.modbus.org](http://www.modbus.org).

Modbus Function Code	Description
1	Read Coil Status
2	Read Input Status
3	Read Holding Registers
4	Read Input Registers
5	Force (Write) Single Coil
6	Preset (Write) Single Register
7	Read Exception Status
15	Force Multiple Coils
16	Preset Multiple Registers

### MB Address in Device

This parameter specifies the starting Modbus register or bit address in the server to be used by the command. Refer to the documentation of each Modbus server device for the register and bit address assignments valid for that device.

The Modbus Function Code determines whether the address will be a register-level or bit-level OFFSET address into a given data type range. The offset will be the target data address in the server minus the base address for that data type.

Base addresses for the different data types are:

- 00001 or 000001 (0x0001) for bit-level Coil data (Function Codes 1, 5, and 15).
- 10001 or 100001 (1x0001) for bit-level Input Status data (Function Code 2)
- 30001 or 300001 (3x0001) for Input Register data (Function Code 4)
- 40001 or 400001 (4x0001) for Holding Register data (Function Codes 3, 6, and 16).

Address calculation examples:

- For bit-level Coil commands (FC 1, 5, or 15) to read or write a Coil 0X address 00001, specify a value of 0 ( $00001 - 00001 = 0$ ).
- For Coil address 00115, specify 114  
( $00115 - 00001 = 114$ )
- For register read or write commands (FC 3, 6, or 16) 4X range, for 40001, specify a value of 0  
( $40001 - 40001 = 0$ ).
- For 01101, 11101, 31101 or 41101, specify a value of 1100.  
( $01101 - 00001 = 1100$ )  
( $11101 - 10001 = 1100$ )  
( $31101 - 30001 = 1100$ )  
( $41101 - 40001 = 1100$ )


**Note:** If the documentation for a particular Modbus server device lists data addresses in hexadecimal (base16) notation, you will need to convert the hexadecimal value to a decimal value to enter in this parameter. In such cases, it is not usually necessary to subtract 1 from the converted decimal number, as this addressing scheme typically uses the exact offset address expressed as a hexadecimal number.

### Comment

0 to 35 alphanumeric characters

## 2.2.7 MNET Servers

This section contains database offset information used by the server when accessed by external Clients. These offsets can be utilized to segment the database by data type.



### Float Flag

#### **YES or NO**

This flag specifies how the server driver will respond to Function Code 3, 6, and 16 commands (read and write Holding Registers) from a remote Client when it is moving 32-bit floating-point data.

If the remote Client expects to receive or will send one complete 32-bit floating-point value for each count of one (1), then set this parameter to **YES**. When set to **YES**, the server driver will return values from two consecutive 16-bit internal memory registers (32 total bits) for each count in the read command, or receive 32-bits per count from the Client for write commands. Example: Count = **10**, server driver will send 20 16-bit registers for 10 total 32-bit floating-point values.

If, however, the remote Client sends a count of two (2) for each 32-bit floating-point value it expects to receive or send, or, if you do not plan to use floating-point data in your application, then set this parameter to **No**, which is the default setting.

You will also need to set the *Float Start* and *Float Offset* parameters to appropriate values whenever the *Float Flag* parameter is set to **YES**.

### Float Start

#### **0 to 65535**

Whenever the *Float Flag* parameter is set to **YES**, this parameter determines the lowest Modbus Address, received in commands from a remote Client, to consider as requests to read or write floating-point data. All commands with address values greater than or equal to this value will be considered floating-point data requests. All commands with address values less than this value will be considered normal 16-bit register data requests.

This parameter is used only if the *Float Flag* is set to **YES**. For example, if a value of 7000 is entered, all commands received with addresses of 47001 (or 407001) and above will be considered as requests for floating-point data and 32-bits of data will be returned for each count of one in the command.

You will also need to set the *Float Offset* parameter to an appropriate value whenever the *Float Flag* parameter is set to **YES**.

### Float Offset

#### **0 to 9999**

This parameter defines the start register for floating-point data in the internal database. This parameter is used only if the *Float Flag* is enabled. For example, if the *Float Offset* value is set to **3000** and the *Float Start* parameter is set to **7000**, data requests for register 7000 will use the internal Modbus register 3000.

### Output Offset

#### **0 to 4999**

This parameter defines the start register for the Modbus command data in the internal database. This parameter is enabled when a value greater than **0** is set. For example, if the *Output Offset* value is set to **3000**, data requests for Modbus Coil Register address 00001 will use the internal database register 3000, bit 0. If the *Output Offset* value is set to **3000**, data requests for Modbus Coil register address 00016 will use the internal database register 3000, bit 15. Function codes affected are 1, 5, and 15.

### Bit Input Offset

#### **0 to 4999**

This parameter defines the start register for Modbus command data in the internal database. This parameter is enabled when a value greater than **0** is set. For example, if the *Bit Input Offset* value is set to **3000**, data requests for Modbus Input Register address 10001 will use the internal database register 3000, bit 0. If the *Bit Input Offset* is set to **3000**, data requests for Modbus Coil register address 10016 will use the internal database register 3000, bit 15. Function code 2 is affected.

*Holding Register Offset*

**0 to 4999**

This parameter defines the start register for the Modbus Command data in the internal database. This parameter is enabled when a value greater than **0** is set. For example, if the *Holding Register Offset* value is set to **4000**, data requests for Modbus Word register 40001 will use the internal database register 4000. Function codes affected are 3, 6, 16, & 23.

*Word Input Offset*

**0 to 4999**

This parameter defines the start register for Modbus Command data in the internal database. This parameter is enabled when a value greater than **0** is set. For example, if the *Word Input Offset* value is set to **4000**, data requests for Modbus Word register address 30001 will use the internal database register 4000. Function code 4 is affected.

*Connection Timeout*

**0 to 1200 seconds**

This is the number of seconds the server will wait to receive new data. If the server does not receive any new data during this time, it will close the connection.



### 2.2.8 Static ARP Table

The Static ARP Table defines a list of static IP addresses that the module will use when an ARP (Address Resolution Protocol) is required. The module will accept up to 40 static IP/MAC address data sets.

Use the Static ARP table to reduce the amount of network traffic by specifying IP addresses and their associated MAC (hardware) addresses that the MVI56E-MNET module will be communicating with regularly.

**Important:** If the device in the field is changed, this table must be updated to contain the new MAC address for the device and downloaded to the module. If the MAC is not changed, no communications with the module will be provided.

#### IP Address

Dotted notation

This table contains a list of static IP addresses that the module will use when an ARP is required. The module will accept up to 40 static IP/MAC address data sets.

**Important:** If the device in the field is changed, this table must be updated to contain the new MAC address for the device and downloaded to the module. If the MAC is not changed, no communications with the module will occur.

#### Hardware MAC Address

Hex value

This table contains a list of static MAC addresses that the module will use when an ARP is required. The module will accept up to 40 static IP/MAC address data sets.

**Important:** If the device in the field is changed, this table must be updated to contain the new MAC address for the device and downloaded to the module. If the MAC is not changed, no communications with the module will occur.


### 2.2.9 Ethernet Configuration

Use this procedure to configure the Ethernet settings for your module. You must assign an IP address, subnet mask and gateway address. After you complete this step, you can connect to the module with an Ethernet cable.

- 1 Determine the network settings for your module, with the help of your network administrator if necessary. You will need the following information:
  - IP address (fixed IP required) \_\_\_\_\_ . \_\_\_\_\_ . \_\_\_\_\_ . \_\_\_\_\_
  - Subnet mask \_\_\_\_\_ . \_\_\_\_\_ . \_\_\_\_\_ . \_\_\_\_\_
  - Gateway address \_\_\_\_\_ . \_\_\_\_\_ . \_\_\_\_\_ . \_\_\_\_\_

**Note:** The gateway address is optional, and is not required for networks that do not use a default gateway.


- 2 Double-click the **ETHERNET CONFIGURATION** icon. This action opens the *Edit* dialog box.



- 3 Edit the values for *my\_ip*, *netmask* (subnet mask) and *gateway* (default gateway).
- 4 When you are finished editing, click **OK** to save your changes and return to the *ProSoft Configuration Builder* window.

## 2.3 Connecting Your PC to the Module


With the module securely mounted, connect one end of the Ethernet cable to the *Config (E1)* Port, and the other end to an Ethernet hub or switch accessible from the same network as your PC. You can also connect directly from the Ethernet Port on your PC to the *Config (E1)* Port on the module by using an Ethernet crossover cable (not included).




### 2.3.1 Setting Up a Temporary IP Address

**Important:** *ProSoft Configuration Builder* locates MVI56E-MNET modules through UDP broadcast messages. These messages may be blocked by routers or layer 3 switches. In that case, *ProSoft Discovery Service* will be unable to locate the modules. To use *ProSoft Configuration Builder*, arrange the Ethernet connection so that there is no router/layer 3 switch between the computer and the module OR reconfigure the router/layer 3 switch to allow routing of the UDP broadcast messages.

- 1 In the tree view in *ProSoft Configuration Builder*, select the **MVI56E-MNET** module.




- 2 Click the right mouse button to open a shortcut menu. On the shortcut menu, choose **DIAGNOSTICS**.




- 3 In the *Diagnostics* window, click the **SET UP CONNECTION** button.



- 4 In the *Connection Setup* dialog box, click the **BROWSE DEVICE(S)** button to open the *ProSoft Discovery Service*. Select the module, then right-click and choose **ASSIGN TEMPORARY IP**.




- 5 The module's default IP address is 192.168.0.250. Choose an unused IP within your subnet, and then click **OK**.




**Important:** The temporary IP address is only valid until the next time the module is initialized. For information on how to set the module's permanent IP address, see Ethernet Configuration (page 58).

- 6 Close the *ProSoft Discovery Service* window. Enter the temporary IP in the Ethernet address field of the *Connection Setup* dialog box, then click the **TEST CONNECTION** button to verify that the module is accessible with the current settings.



- 7 If the *Test Connection* is successful, click **CONNECT**. The *Diagnostics* menu will display in the *Diagnostics* window.



## 2.4 Downloading the Project to the Module


**Note:** For alternative methods of connecting to the module with your PC, refer to Using CIPconnect to Connect to the Module (page 64) or Using RSWho to Connect to the Module (page 73).

In order for the module to use the settings you configured, you must download (copy) the updated Project file from your PC to the module.

- 1 In the tree view in *ProSoft Configuration Builder*, click once to select the **MVI56E-MNET** module.

- 2 Open the **PROJECT** menu, and then choose **MODULE / DOWNLOAD**.

This action opens the *Download* dialog box. Notice that the Ethernet address field contains the temporary IP address you assigned previously. *ProSoft Configuration Builder* will use this temporary IP address to connect to the module.




Click **TEST CONNECTION** to verify that the IP address allows access to the module.

- 3 If the connection succeeds, click **DOWNLOAD** to transfer the Ethernet configuration to the module.

If the *Test Connection* procedure fails, you will see an error message. To correct the error, follow these steps.

- 1 Click **OK** to dismiss the error message.
- 2 In the *Download* dialog box, click **BROWSE DEVICE(S)** to open *ProSoft Discovery Service*.



- 3 Select the module, and then click the right mouse button to open a shortcut menu. On the shortcut menu, choose **SELECT FOR PCB**.
- 4 Close *ProSoft Discovery Service*.
- 5 Click **DOWNLOAD** to transfer the configuration to the module.

### 2.4.1 Using CIPconnect to Connect to the Module


You can use CIPconnect<sup>®</sup> to connect a PC to the MVI56E-MNET module over Ethernet using Rockwell Automation's 1756-ENBT EtherNet/IP<sup>®</sup> module. This allows you to configure the MVI56E-MNET module and network, upload and download files, and view network and module diagnostics from a PC. RSLinx is not required when you use CIPconnect. All you need are:

- The IP addresses and slot numbers of any 1756-ENBT modules in the path
- The ControlNet node numbers and slot numbers of any 1756-CNBx ControlNet Bridge modules in the path
- The slot number of the MVI56E-MNET in the destination ControlLogix chassis (the last ENBT/CNBx and chassis in the path).


To use CIPconnect, follow these steps.



- 1 In the *Select Connection Type* dropdown list, choose **1756-ENBT**. The default path appears in the text box, as shown in the following illustration.



- 2 Click **CIP PATH EDIT** to open the *CIPconnect Path Editor* dialog box.



The *CIPconnect Path Editor* allows you to define the path between the PC and the MVI56E-MNET module. The first connection from the PC is always a 1756-ENBT (Ethernet/IP) module.

Each row corresponds to a physical rack in the CIP path.

- If the MVI56E-MNET module is located in the same rack as the first 1756-ENBT module, select **RACK No. 1** and configure the associated parameters.
- If the MVI56E-MNET is available in a remote rack (accessible through ControlNet or Ethernet/IP), include all racks (by using the **ADD RACK** button).


Parameter	Description
Source Module	Source module type. This field is automatically selected depending on the destination module of the last rack (1756-CNB or 1756-ENBT).
Source Module IP Address	IP address of the source module (only applicable for 1756-ENBT)
Source Module Node Address	Node address of the source module (only applicable for 1756-CNB)
Destination Module	Select the destination module associated to the source module in the rack. The connection between the source and destination modules is performed through the backplane.
Destination Module Slot Number	The slot number where the destination MVI56E module is located.

To use the CIPconnect Path Editor, follow these steps.

- 1 Configure the path between the 1756-ENBT connected to your PC and the MVI56E-MNET module.
  - If the module is located in a remote rack, add more racks to configure the full path.
  - The path can only contain ControlNet or Ethernet/IP networks.
  - The maximum number of supported racks is six.
- 2 Click **CONSTRUCT CIP PATH** to build the path in text format
- 3 Click **OK** to confirm the configured path.

#### Example 1: Local Rack Application


For this example, the MVI56E-MNET module is located in the same rack as the 1756-ENBT that is connected to the PC.




### Rack 1

Slot	Module	Network Address
0	ControlLogix Processor	-
1	Any	-
2	MVI56E-MNET	-
3	1756-ENBT	IP=192.168.0.100

- 1 In the *Download* dialog box, click **CIP PATH EDIT**.




- 2 Configure the path as shown in the following illustration, and click **CONSTRUCT CIP PATH** to build the path in text format.




Click **OK** to close the *CIPconnect Path Editor* and return to the *Download* dialog box.


- 3 Check the new path in the *Download* dialog box.



- 4 Click **TEST CONNECTION** to verify that the physical path is available. The following message should be displayed upon success.




- 5 Click **OK** to close the Test Connection pop-up and then click **DOWNLOAD** to download the configuration files to the module through the path.



**Example 2: Remote Rack Application**

For this example, the MVI56E-MNET module is located in a remote rack accessible through ControlNet, as shown in the following illustration.




### Rack 1

Slot	Module	Network Address
0	ControlLogix Processor	-
1	1756-CNB	Node = 1
2	1756-ENBT	IP=192.168.0.100
3	Any	-


### Rack 2

Slot	Module	Network Address
0	Any	-
1	Any	-
2	Any	-
3	Any	-
4	Any	-
5	1756-CNB	Node = 2
6	MVI56E-MNET	-

- 1 In the *Download* dialog box, click **CIP PATH EDIT**.




- 2 Configure the path as shown in the following illustration and click **CONSTRUCT CIP PATH** to build the path in text format.




Click **OK** to close the *CIPconnect Path Editor* and return to the *Download* dialog box.


- 3 Check the new path in the *Download* dialog box.



- Click **TEST CONNECTION** to verify that the physical path is available. The following message should be displayed upon success.



- Click **DOWNLOAD** to download the configuration files to the module through the path.







## 2.4.2 Using RSWho to Connect to the Module

You need to have RSLinx installed on your PC to use this feature. You also need an ENBT module set up in the rack. For information on setting up the ENBT module, see Using CIPconnect to Connect to the Module (page 64).

- 1 In the tree view in *ProSoft Configuration Builder*, right-click the **MVI56E-MNET** module.
- 2 From the shortcut menu, choose **DOWNLOAD FROM PC TO DEVICE**.
- 3 In the *Download* dialog box, choose **1756 ENBT** from the *Select Connection Type* dropdown box.



- 4 Click **RSWho** to display modules on the network. The MVI56E-MNET module will automatically be identified on the network.



- 5 Select the module, and then click **OK**.
- 6 In the *Download* dialog box, click **DOWNLOAD**.



## 3 Ladder Logic

### In This Chapter

❖ Controller Tags.....	76
❖ User-Defined Data Types (UDTs) .....	78
❖ Using Controller Tags.....	79
❖ Controller Tag Overview.....	80

\

Ladder logic is required for managing communication between the MVI56E-MNET module and the processor. The ladder logic handles tasks such as:

- Module backplane data transfer
- Special block handling
- Status data receipt

Additionally, a power-up handler may be needed to initialize the module's database and may clear some processor fault conditions.

The sample Import Rung with Add-On Instruction is extensively commented to provide information on the purpose and function of each user-defined data type and controller tag. For most applications, the Import Rung with Add-On Instruction will work without modification.

## 3.1 Controller Tags

Data related to the MVI56E-MNET is stored in the ladder logic in variables called controller tags. Individual controller tags can be grouped into collections of controller tags called controller tag structures. A controller tag structure can contain any combination of:


- Individual controller tags
- Controller tag arrays
- Lower-level controller tag structures

The controller tags for the module are pre-programmed into the Add-On Instruction Import Rung ladder logic. You can find them in the *Controller Tags* subfolder, located in the *Controller* folder in the *Controller Organizer* pane of the main RSLogix 5000 window.

This controller tag structure is arranged as a tree structure. Individual controller tags are found at the lowest level of the tree structure. Each individual controller tag is defined to hold data of a specific type, such as integer or floating-point data. Controller tag structures are declared with user-defined data types, which are collections of data types.

### 3.1.1 MVI56(E)-MNET Controller Tags

The main controller tag structure, *MNET*, is broken down into four lower-level controller tag structures:



The four lower-level controller tag structures contain other controller tags and controller tag structures. Click the **[+]** sign next to any controller tag structure to expand it and view the next level in the structure.

For example, if you expand the *MNET.DATA* controller tag structure, you will see that it contains two controller tag arrays, *MNET.DATA.ReadData* and *MNET.DATA.WriteData*, which are 600-element integer arrays by default.

Scope: <span>My_Controller</span> <span>Show...</span> <span>Show All</span>				
	Name	Value	Data Type	Description
+	ADI56MNET	{ ... }	ADI56MNET	Add-On - MVI56-MN
-	MNET	{ ... }	MNETMODULEDEF	Output parameters.
-	MNET.DATA	{ ... }	MNETDATA	Output parameters.
+	MNET.DATA.ReadData	{ ... }	INT[600]	Output parameters.
+	MNET.DATA.WriteData	{ ... }	INT[600]	Output parameters.
+	MNET.STATUS	{ ... }	MNETSTATUS	Output parameters.
+	MNET.CONTROL	{ ... }	MNETCONTROL	Output parameters.
+	MNET.UTIL	{ ... }	MNETUTIL	Output parameters.

Each controller tag in the Add-On Instruction is commented in the *Description* column.

Notice that the *Data Type* column displays the data types used to declare each controller tag, controller tag array or controller tag structure. Individual controller tags are declared with basic data types, such as INT and BOOL. Controller tag arrays are declared with arrays of basic data types. Controller tag structures are declared with user-defined data types (UDTs).

## 3.2 User-Defined Data Types (UDTs)

User-defined data types (UDTs) allow users to organize collections of data types into groupings. These groupings, or data type structures, can then be used to declare the data types for controller tag structures. Another advantage of defining a UDT is that it may be re-used in other controller tag structures that use the same data types.

The Add-On Instruction Import Rung ladder logic for the module has pre-defined UDTs. You can find them in the *User-Defined* subfolder, located in the *Data Types* folder in the *Controller Organizer* pane of the main RSLogix window. Like the controller tags, the UDTs are organized in a multiple-level tree structure.

### 3.2.1 MVI56(E)-MNET User-Defined Data Types

Twelve different UDTs are defined for the MVI56(E)-MNET Add-On Instruction. The main UDT, *MNETMODULEDEF*, contains all the data types for the module and was used to create the main controller tag structure, *MNET*. There are four UDTs one level below *MNETMODULEDEF*. These lower-level UDTs were used to create the *MNET.DATA*, *MNET.STATUS*, *MNET.CONTROL*, and *MNET.UTIL* controller tag structures.

The screenshot shows the RSLogix Controller Organizer window. At the top, the 'Name' field is set to 'MNETMODULEDEF'. Below it, the 'Description' field contains the text: 'This defines the whole module which includes all tags used in the program'. Under the 'Members' section, there is a table listing four UDTs: DATA, STATUS, CONTROL, and UTIL. Each row has a plus sign icon in the first column, indicating they can be expanded. The table also includes columns for Name, Data Type, Style, and Description.

Members:		Data Type Size: ?? byte(s)		
	Name	Data Type	Style	Description
+	DATA	MNETDATA		Data read from module
+	STATUS	MNETSTATUS		Client ,Server Status and blocks status
+	CONTROL	MNETCONTROL		MNET Module control warmboot, coldboot, etc
+	UTIL	MNETUTIL		command, event control

Click the **[+]** signs to expand the UDT structures and view lower-level UDTs.

For example, if you expand *MNETDATA*, you will see that it contains two UDTs, *ReadData* and *WriteData*. Both of these are 600-element integer arrays by default.

The screenshot shows the 'MNETMODULEDEF' configuration window. The 'Name' field is 'MNETMODULEDEF'. The 'Description' field contains the text: 'This defines the whole module which includes all tags used in the program'. Below this is a 'Members' table with the following data:

Members:		Data Type Size: ?? byte(s)	
	Name	Data Type	Style
	DATA	MNETDATA	
	ReadData	INT[600]	Decimal
	WriteData	INT[600]	Decimal
	STATUS	MNETSTATUS	
	CONTROL	MNETCONTROL	
	UTIL	MNETUTIL	

The 'Description' column for each member is as follows:

- DATA: Data read from module
- ReadData: Data read from module. Set array equal to the size set in th
- WriteData: Data to write to module. Set array equal to the size set in t
- STATUS: Client ,Server Status and blocks status
- CONTROL: MNET Module control warmboot, coldboot, etc
- UTIL: command, event control

Notice that these UDTs are the data types used to declare the *MNET.DATA.ReadData* and *MNET.DATA.WriteData* controller tag arrays. Each UDT is commented in the *Description* column.

### 3.3 Using Controller Tags

You can use controller tags to:

- View read and write data that is being transferred between the module and the processor.
- View status data for the module.
- Set up and trigger special functions.
- Initiate module restarts (Warm Boot or Cold Boot).

### 3.4 Controller Tag Overview

Controller Tag	Description
MNET.DATA	MNET input and output data transferred between the processor and the module
MNET.STATUS	Status information
MNET.CONTROL	Governs the data movement between the PLC rack and the module
MNET.UTIL	Generic tags used for internal ladder processing (DO NOT MODIFY)

The following sections describe each of these controller tag structures in more detail.

#### 3.4.1 MNET.DATA

The controller tags in *MNET.DATA* hold user data to be transferred between the processor and the MVI56E-MNET module. This read and write data is transferred between the processor and the module as "pages," or blocks, of data up to 200 words long.


The data types for the *MNET.DATA.ReadData* and *MNET.DATA.WriteData* controller tag arrays are integer arrays containing variable numbers of elements.

Controller Tag	Data Type	Description
ReadData	INT[x]	Data read from module. Array size is equal to the size set in the configuration.
WriteData	INT[x]	Data to write to module. Array size is equal to the size set in the configuration.



### *MNET.DATA.ReadData*

*ReadData* is a controller tag array that automatically adjusts to match the value entered in the *Read Register Count* (page 42) parameter of the configuration. For ease of use, this array should be dimensioned as a multiple of 200 words. This data is paged up to 200 words at a time from the module to the processor. The ladder logic places the received data into the proper position in the *ReadData* array. This data is used for status and control in the processor ladder logic.




The *ReadData* array is related to the contents of the Read Data area of the module's internal database. To view the actual registers in the module's internal database, access the database display from *ProSoft Configuration Builder's Diagnostics* menu. For more information, see the section on *PCB Diagnostics* (page 96).

DATABASE DISPLAY 0 TO 99 (DECIMAL)

6666	7777	8888	9999	1010	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0

### *MNET.DATA.WriteData*

*WriteData* is a controller tag array that automatically adjusts to match the value entered in the *Write Register Count* (page 43) parameter of the configuration. For ease of use, this array should be dimensioned as a multiple of 200 words. This data is paged up to 200 words at a time from the processor to the module. The ladder logic places the write data into the output image for transfer to the module. This data is passed from the processor to the module for status and control information for use in other nodes on the network.



The *WriteData* array is related to the contents of the Write Data area of the module's internal database. To view the actual registers in the module's internal database, access the database display from *ProSoft Configuration Builder's Diagnostics* menu. For more information, see the section on *PCB Diagnostics* (page 96).

#### DATABASE DISPLAY 1000 TO 1099 (DECIMAL)

1111	2222	3333	4444	5555	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0

### 3.4.2 MNET.STATUS

The *MNET.STATUS* controller tag structure has several lower-level controller tag structures. A few of them are described below.

#### *MNET.STATUS.PassCnt*

This is the Program Scan Counter value. It is incremented by a count of 1 each time a module's program cycle is complete.

#### *MNET.STATUS.ClientStats*

Controller Tag	Description
CmdReq	This value in this tag is incremented each time a Command Request is issued by the Client.
CmdResp	This value in this tag is incremented each time a Command Response is received by the Client.
CmdErr	This value in this tag is incremented each time an error message is received from a remote unit or a local error is generated for a command.
Requests	This value in this tag is incremented each time a request message is issued.
Responses	This value in this tag is incremented each time a response message is received.
ErrSent	Reserved.
ErrRec	Reserved.
CfgErrWord	Applicable to Clients and servers. This word encodes several potential errors using a bitmap. For more information on the meanings of the various bits when set, see Configuration Error Word (page 104).
CurrErr	Applicable to Clients and servers. Current error code number detected by the module.
LastErr	Applicable to Clients and servers. Previous error detected by the module.

#### *MNET.STATUS.BlockStats*

These tags display the backplane Block Transfer statistics.

Controller Tag	Description
Read	This tag contains the total number of Read blocks transferred from the module to the processor.
Write	This tag contains the total number of Write blocks transferred from the processor to the module.
Parse	This tag contains the total number of blocks successfully parsed that were received from the processor.
Event	This tag contains the total number of Event Command blocks received from the processor.
Cmd	This tag contains the total number of Command Control blocks received from the processor.
Err	This tag contains the total number of block Errors recognized by the module.

For a more complete description of the *MNET.STATUS* controller tag structure, refer to the Status Data Definition (page 102).

### 3.4.3 MNET.CONTROL

These controller tags are a 'scratchpad' area of intermediate data storage variables used by the ladder logic to keep track of various logic processing functions.

Controller Tag	Description
WarmBoot	Setting this tag to 1 will cause the module to reload, refreshing configuration parameters that must be set on program initialization. Only use this command if you must cause the module to re-boot.
ColdBoot	Set this tag to 1 when the module is required to perform the cold boot (hardware reset) operation. Do this when the module is experiencing a hardware problem requiring a hardware reset.
BPLastRead	This tag stores the latest Read Block ID received from the module. This value changes frequently.
BPLastWrite	This tag stores the latest Write Block ID to be sent to the module. This value changes frequently.
BlockIndex	This tag is an intermediate variable used during the block calculation.
WBPending	Pending message
CBPending	Pending message
ReadDataBlkCount	Holds the value of the Block Counts of the Read Data Array. Array size is the <i>Read Register Count</i> divided by 200.
WriteDataBlkCount	Holds the value of the Block Counts of the Write Data Array. Array size is the <i>Write Register Count</i> divided by 200.
RBTsremainder	Holds remainder calculation value from the read array.
WBTSremainder	Holds remainder calculation value from the write array.
ReadDataSizeGet	Holds read data array size.
WriteDataSizeGet	Holds write data array size.
IPAddress	Getting and setting IP address to and from the module.
FaultCode	Fault Code value
CheckInitialization	Check Initialization trigger

The *LastRead* tag stores the latest Read Block ID received from the module. The *LastWrite* tag stores the latest Write Block ID to be sent to the module. The *BlockIndex* tag is an intermediate variable used during the block calculation.

### 3.4.4 MNET.UTIL

Controller Tag	Description
CmdControl	This group of tags is used to control special or irregular execution of the commands listed in the configuration under the MNet Client 0 Commands section, regardless of whether or not such commands are normally enabled or disabled.
EventCmd	This group of tags is used to create and have the Client execute a special ladder logic constructed command that is not included in the MNet Client 0 Commands section of the configuration file.
InitOutputData	This group of tags is used for setting up data values when the module performs a restart operation. It will request the processor's output data and transfer it into the module's Modbus registers. Use the <i>Initialize Output Data</i> parameter in the configuration file to bring the module to a known state after a restart operation.
PassThru	This group of tags is used for transferring a remote Client's write commands through the MNET module straight into the processor's controller tags without first storing the data in the module's Modbus registers.
IPsetPending	Allows setting module IP address
IPgetPending	Allows getting module IP address

For more information, refer to Special Function Blocks (page 119).



## 4 Diagnostics and Troubleshooting

### In This Chapter

- ❖ LED Status Indicators..... 88
- ❖ Using the Diagnostics Menu in ProSoft Configuration Builder..... 92
- ❖ Reading Status Data from the Module ..... 101

The module provides information on diagnostics and troubleshooting in the following forms:

- LED status indicators on the front of the module provide information on the module's status.
- Status data contained in the module can be viewed in *ProSoft Configuration Builder* through the Ethernet port.
- Status data values are transferred from the module to the processor.

## 4.1 LED Status Indicators

### 4.1.1 Scrolling LED Status Indicators

The scrolling LED display indicates the module's operating status as follows:

#### Initialization Messages

Code	Message
Boot / DDOK	Module is initializing
Ladd	Module is waiting for required module configuration data from ladder logic to configure the application port(s)
Waiting for Processor Connection	Module did not connect to processor during initialization <ul style="list-style-type: none"> <li>Sample ladder logic or AOI is not loaded on processor</li> <li>Module is located in a different slot than the one configured in the ladder logic/AOI</li> <li>Processor is not in RUN or REM RUN mode</li> </ul>
Last config: <date>	Indicates the last date when the module changed its IP address. You can update the module date and time through the module's web page, or with the optional MVI56E Advanced Add-On Instruction.
C0 (Client): CmdCnt: X MinDly : X CmdOffs: X RespTmout : X Retries : X ErrOffs : X ARPTmout : X ErrDelay : X FltFlag : X FltSt : X FltOffs : X SVR (server) : BOffs: X WIOffs : X OutOffs : X HoldOffs : X FltFlag : X FltSt : X FltSt : X CommTmout : X	After power up and every reconfiguration, the module will display the configuration of the application port(s). The information consists of: <p><b>Client</b></p> <ul style="list-style-type: none"> <li>CmdCnt : number of commands configured for the Client</li> <li>MinDly : Minimum Command Delay parameter</li> <li>CmdOffs : Command Error Pointer parameter</li> <li>RespTmout : Response Timeout parameter</li> <li>Retries : Retry Count parameter</li> <li>ErrOffs : Error/Status Offset parameter</li> <li>ARPTmout : ARP Timeout parameter</li> <li>ErrDelay: Command Error Delay parameter</li> <li>FltFlag: Float Flag parameter</li> <li>Flt St : Float Start parameter</li> <li>FltOffs : Float Offset parameter</li> </ul> <p><b>Server</b></p> <ul style="list-style-type: none"> <li>BOffs: Bit Input Offset parameter</li> <li>WIOffs : Word Input Offset parameter</li> <li>OutOffs : Output offset parameter</li> <li>HoldOffs : Holding Register offset parameter</li> <li>FltFlag: Float Flag parameter</li> <li>FltSt : Float Start parameter</li> <li>FltOffs : Float Offset parameter</li> </ul>



### Operation Messages

After the initialization step, the following message pattern will be repeated.

<Backplane Status> <IP Address> <Backplane Status> <Port Status>

Code	Message
<Backplane Status>	OK: Module is communicating with processor ERR: Module is unable to communicate with processor. For this scenario, the <Port Status> message above is replaced with "Processor faulted or is in program mode".
<IP Address>	Module IP address
<C0>	OK: Port is communicating without error Communication Errors: port is having communication errors. Refer to Diagnostics and Troubleshooting (page 87) for further information about the error.

### 4.1.2 Ethernet LED Indicators

The Ethernet LEDs indicate the module's Ethernet port status as follows:

LED	State	Description
Data	OFF	Ethernet connected at 10Mbps duplex speed
	AMBER Solid	Ethernet connected at 100Mbps duplex speed
Link	OFF	No physical network connection is detected. No Ethernet communication is possible. Check wiring and cables.
	GREEN Solid or Blinking	Physical network connection detected. This LED must be ON solid for Ethernet communication to be possible.

### 4.1.3 Non-Scrolling LED Status Indicators

The non-scrolling LEDs indicate the module's operating status as follows:

LED Label	Color	Status	Indication
APP	Red or Green	OFF	The module is not receiving adequate power or is not securely plugged into the rack. May also be OFF during configuration download.
		GREEN	The MVI56E-MNET is working normally.
		RED	The most common cause is that the module has detected a communication error during operation of an application port. The following conditions may also cause a RED LED: <ul style="list-style-type: none"> <li>▪ The firmware is initializing during startup</li> <li>▪ The firmware detects an on-board hardware problem during startup</li> <li>▪ Failure of application port hardware during startup</li> <li>▪ The module is shutting down</li> <li>▪ The module is rebooting due to a ColdBoot or WarmBoot request from the ladder logic or Debug Menu</li> </ul>
OK	Red or Green	OFF	The module is not receiving adequate power or is not securely plugged into the rack.
		GREEN	The module is operating normally.
		RED	The module has detected an internal error or is being initialized. If the LED remains RED for over 10 seconds, the module is not working. Remove it from the rack and re-insert it to restart its internal program.
ERR			Not Used

#### 4.1.4 Troubleshooting

Use the following troubleshooting steps if you encounter problems when the module is powered up. If these steps do not resolve your problem, please contact ProSoft Technology Technical Support.

##### Processor Errors

Problem Description	Steps to take
Processor Fault	Verify that the module is plugged into the slot that has been configured for the module in the I/O Configuration of RSLogix. Verify that the slot location in the rack has been configured correctly in the ladder logic.
Processor I/O LED flashes	This indicates a problem with backplane communications. A problem could exist between the processor and any installed I/O module, not just the MVI56E-MNET. Verify that all modules in the rack are correctly configured in the ladder logic.

##### Module Errors

Problem Description	Steps to take
MVI56E modules with scrolling LED display: <i>&lt;Backplane Status&gt;</i> condition reads ERR	This indicates that backplane transfer operations are failing. Connect to the module's Configuration/Debug port to check this. To establish backplane communications, verify the following items: <ul style="list-style-type: none"> <li>▪ The processor is in RUN or REM RUN mode.</li> <li>▪ The backplane driver is loaded in the module.</li> <li>▪ The module is configured for read and write data block transfer.</li> <li>▪ The ladder logic handles all read and write block situations.</li> <li>▪ The module is properly configured in the processor I/O configuration and ladder logic.</li> </ul>
OK LED remains RED	The program has halted or a critical error has occurred. Connect to the Configuration/Debug port to see if the module is running. If the program has halted, turn off power to the rack, remove the card from the rack and re-insert the card in the rack, and then restore power to the rack.

#### 4.1.5 Clearing a Fault Condition

Typically, if the OK LED on the front of the module turns RED for more than ten seconds, a hardware problem has been detected in the module or the program has exited.

To clear the condition, follow these steps:

- 1 Turn off power to the rack.
- 2 Remove the card from the rack.
- 3 Verify that all jumpers are set correctly.
- 4 If the module requires a Compact Flash card, verify that the card is installed correctly.
- 5 Re-insert the card in the rack and turn the power back on.
- 6 Verify correct configuration data is being transferred to the module from the ControlLogix controller.


If the module's OK LED does not turn GREEN, verify that the module is inserted completely into the rack. If this does not cure the problem, contact ProSoft Technology Technical Support.

## 4.2 Using the Diagnostics Menu in ProSoft Configuration Builder


**Tip:** You can have a ProSoft Configuration Builder *Diagnostics* window open for more than one module at a time.

To connect to the module's Configuration/Debug Ethernet port:

- 1 In *ProSoft Configuration Builder*, select the module, and then click the right mouse button to open a shortcut menu.



- 2 On the shortcut menu, choose **DIAGNOSTICS**.




- 3 In the *Diagnostics* window, click the **SET UP CONNECTION** button to browse for the module's IP address.




**Click to set up connection**

- 4 In the *Connection Setup* dialog box, click the **TEST CONNECTION** button to verify that the module is accessible with the current settings.




You can also use CIPconnect<sup>®</sup> to connect to the module through a 1756-ENBT card. Refer to *Using CIPconnect to Connect to the Module* (page 64) for information on how to construct a CIP path.



- 5 If the *Test Connection* is successful, click **CONNECT**.

If *PCB* is unable to connect to the module:

- 1 Click the **BROWSE DEVICE(S)** button to open the *ProSoft Discovery Service*.  
Select the module, then right-click and choose **SELECT FOR PCB**.




- 2 Close *ProSoft Discovery Service*, and click the **CONNECT** button again.
- 3 If these troubleshooting steps fail, verify that the Ethernet cable is connected properly between your computer and the module, either through a hub or switch (using the grey cable) or directly between your computer and the module (using the red cable).

If you are still not able to establish a connection, contact ProSoft Technology for assistance.


### 4.2.1 Connecting to the Module's Web Page

The module's internal web server provides access to general product information, firmware download link, and links to ProSoft Technology's Web site.

- 1 In *ProSoft Discovery Service*, select the module, and then click the right mouse button to open a shortcut menu.




- 2 On the shortcut menu, choose **VIEW MODULE'S WEBPAGE**.



## 4.2.2 The Diagnostics Menu

The *Diagnostics* menu, available through the Ethernet configuration port for this module, is arranged as a tree structure, with the *Main* menu at the top of the tree, and one or more submenus for each menu command. The first menu you see when you connect to the module is the *Main* menu.



## 4.2.3 Monitoring Module Information

Use the *MODULE* menu to view configuration and hardware information for the MVI56E-MNET module's backplane and Ethernet application port.

### Version

Use the *Version* menu to view module hardware and firmware information.

```
MVI56E-MNET_SLOT4 > MODULE > Version :
PRODUCT NAME CODE           :MNE5
SOFTWARE REVISION LEVEL     :2.02
OPERATING SYSTEM REVISION   :0609
RUN NUMBER                   :0901
PROGRAM SCAN COUNTER        :11849
IP ADDRESS                   :105.102.0.4
ETHERNET ADDRESS (MAC)      :00:0d:8d:00:3a:9d
BACKPLANE DRIVER VERSION    :2.06
BACKPLANE API VERSION       :1.01
MODULE NAME                  :MVI56E-MNET
VENDOR ID                   :309
DEVICE TYPE                  :12
PRODUCT CODE                 :5004
SERIAL NUMBER                :000003EC
REVISION                     :2.02
SLOT                         :1
```



### Config

Use the *Configuration* menu to view backplane configuration settings for the MVI56E-MNET module.

The information on this menu corresponds with the configuration information in the *Module* settings in *ProSoft Configuration Builder*.

### NIC Status

Use the *NIC Status* (Network Interface Card) menu to view configuration and status information for the MVI56E-MNET module's Ethernet application port.

The information on this menu is useful for troubleshooting Ethernet network connectivity problems.

### Static ARP

Use the *Static ARP* menu to view the list of IP and MAC addresses that are configured not to receive ARP (Address Resolution Protocol) messages from the module.

The Static ARP Table (page 57) defines a list of static IP addresses that the module will use when an ARP is required.

## **4.2.4 Monitoring Backplane Information**

Use the *BACKPLANE* menu to view the backplane status information for the MVI56E-MNET module.

### Backplane Status

Use the *Status* menu to view current backplane status, including

- Number of retries
- Backplane status
- Fail count
- Number of words read
- Number of words written
- Number of words parsed
- Error count
- Event count
- Command count

During normal operation, the read, write, and parsing values should increment continuously, while the error value should not increment.

The status values on this menu correspond with members of the Status Data Definition (page 102).

#### **4.2.5 Monitoring MNET Client Information**

Use the *MNET CLIENT* x menu to view the configuration and status information for the MNET Client(s).

##### Config

Use the *Configuration* menu to view configuration settings for MNET Client x. The information on this menu corresponds with the configuration information in the *MNET Client x* settings in *ProSoft Configuration Builder*.

##### Status

Use the *Status* menu to view status for MNET Client x. During normal operation, the number of requests and responses should increment, while the number of errors should not change.

##### Command List

Use the *Command List* menu to view the command list settings for MNET Client x. The information on this menu corresponds with the *MNET Client x Commands* settings in *ProSoft Configuration Builder*.

Use the scroll bar on the right edge of the window to view each MNET Client command.

##### Command Status

Use the *Command Status* menu to view MNET Client x Command status.

A zero indicates no error.

A non-zero value indicates an error. For an explanation of each value, refer to Client Command Error (page 105).

#### **4.2.6 Monitoring MNET Server Information**

Use the *MNET SERVER* menu to view the configuration and status information for the MNET server.

##### Config

Use the *Configuration* menu to view configuration settings for MNET servers connected to the MNET Client.

The information on this menu corresponds with the configuration information in the *MNET Servers* settings in *ProSoft Configuration Builder* (page 54).

##### Status

Use the *Status* menu to view the status of each MNET server connected to the MNET Client 0. During normal operation, the number of requests and responses should increment, while the number of errors should not change.

## 4.2.7 Monitoring Database Information

Use the *DATABASE* menu to view the contents of the MVI56E-MNET module's internal database.

You can view data in the following formats:

### ASCII

```

DATABASE DISPLAY 0 to 99 (ASCII) :
< @ b y y y ü y  0 0 0 0 0 0
! # % $ ' & ( 1 0 3 2 5 4 7 6 9 8
A @ C B E D G F I H Q P S R U T W V Y X
a c b e d g f i h q p s r u t w v y x
0 0 f , ... " % ' & ( 1 0 3 2 5 4 7 6 9 8
! # % $ ' & ( 1 0 3 2 5 4 7 6 9 8
A @ C B E D G F I H Q P S R U T W V Y X
a c b e d g f i h q p s r u t w v y x
0 0 f , ... " % ' & ( 1 0 3 2 5 4 7 6 9 8

```

### Decimal

```

DATABASE DISPLAY 0 to 99 (DECIMAL) : [Refresh Counter: 3]
-29404      -2      -3      -4      0      1      2      3      4      6169
 8225      8739      9253      9767      10281      12337      12851      13365      13879      14393
16449      16963      17477      17991      18505      20561      21075      21589      22103      22617
24673      25187      25701      26215      26729      28785      29299      29813      30327      30841
-32639      -32125      -31611      -31097      -30583      -28527      -28013      -27499      -26985      -26471
 1      515      1029      1543      2057      4113      4627      5141      5655      6169
 8225      8739      9253      9767      10281      12337      12851      13365      13879      14393
16449      16963      17477      17991      18505      20561      21075      21589      22103      22617
24673      25187      25701      26215      26729      28785      29299      29813      30327      30841
-32639      -32125      -31611      -31097      -30583      -28527      -28013      -27499      -26985      -26471

```

### Float

```

DATABASE DISPLAY 0 to 49 (FLOAT) : [Refresh Counter: 5]
-1.#QNAN000E+000-1.#QNAN000E+000 9.18354962E-041 2.75509291E-040 1.97747944E-024
2.21076282E-018 5.79887491E-016 6.44492959E-010 1.68752010E-007 4.41579286E-005
4.88127480E+001 1.27530674E+004 1.40447017E+010 3.66483682E+012 9.55859400E+014
1.04858893E+021 2.73179652E+023 2.98848446E+029 7.77852805E+031 2.02388230E+034
-1.93224776E-037-5.09760759E-035-5.74027813E-029-1.51029685E-026-3.97016299E-024
9.62436112E-038 2.53936311E-035 2.86023979E-029 7.52614210E-027 1.97859390E-024
2.21076282E-018 5.79887491E-016 6.44492959E-010 1.68752010E-007 4.41579286E-005
4.88127480E+001 1.27530674E+004 1.40447017E+010 3.66483682E+012 9.55859400E+014
1.04858893E+021 2.73179652E+023 2.98848446E+029 7.77852805E+031 2.02388230E+034
-1.93224776E-037-5.09760759E-035-5.74027813E-029-1.51029685E-026-3.97016299E-024

```

### Hexadecimal

```

DATABASE DISPLAY 0 to 99 (HEXADECIMAL) :
907E FFFE FFFD FFFC 0000 0001 0002 0003 0004 1819
2021 2223 2425 2627 2829 3031 3233 3435 3637 3839
4041 4243 4445 4647 4849 5051 5253 5455 5657 5859
6061 6263 6465 6667 6869 7071 7273 7475 7677 7879
8081 8283 8485 8687 8889 9091 9293 9495 9697 9899
0001 0203 0405 0607 0809 1011 1213 1415 1617 1819
2021 2223 2425 2627 2829 3031 3233 3435 3637 3839
4041 4243 4445 4647 4849 5051 5253 5455 5657 5859
6061 6263 6465 6667 6869 7071 7273 7475 7677 7879
8081 8283 8485 8687 8889 9091 9293 9495 9697 9899

```

Use the scroll bar on the right edge of the window to view each page (100 words) of data.

### 4.3 Reading Status Data from the Module

Module status information is useful for troubleshooting and can be accessed in several different ways.

**In the ladder logic's *MNET.STATUS* controller tag structure.**

The MVI56E-MNET module returns status data in the input image that can be used to determine the module's operating status. This data is transferred from the module to the ControlLogix processor continuously as part of the normal data transfer block sequence (page 113). You can view this data in the *MNET.STATUS* controller tag structure in the ladder logic. For more information, see the Status Data Definition (page 102).

**In *ProSoft Configuration Builder's* Diagnostics screens.**

For more information, see the section on PCB Diagnostics (page 96).

**In database locations specified by *Error/Status Pointers* (optional).**

If optional *Error/Status Pointers* are enabled, the status data can also be found in the Read Data area of the module's database at the locations specified by the pointer configuration parameters. For more information, see Backplane Error/Status Pointer (page 42), Client Error/Status Pointer (page 44) and Command Error Pointer (page 45).

### 4.3.1 Status Data Definition

The following is a description of the controller tags in the *MNETR.STATUS* controller tag structure, which contains module, server and Client status data.

Controller Tag	Data Type	Description
PassCnt	INT	This value is incremented each time a complete program cycle occurs in the module.
ProductVersion	INT	This register displays the module software version number in decimal values. For example, if the version number is 1.51, it will display as 151.
ProductCode	INT(2)	Module product code
MnetServStats.CmdReq	INT	Not used
MnetServStats.CmdResp	INT	Not used
MnetServStats.CmdErr	INT	Not used
MnetServStats.Requests	INT	This counter increments each time an MNet (port 2000) request is received.
MnetServStats.Responses		This counter is incremented each time an MNet (port 2000) response message is sent.
MnetServStats.ErrSent	INT	This counter increments each time an MNet (port 2000) sends an exception response to Client. Example: Client sent illegal Modbus Data location address.
MnetServStats.ErrRec	INT	This counter increments each time an MNet (port 2000) receives a bad command. Example: Client sent illegal function command.
MnetServStats.CfgErrWord	INT	Error Configuration Word - Contains a bitmap that indicates Client and server configuration errors
MnetServStats.CurrErr	INT	Not used
MnetServStats.LastErr	INT	Not used
MBAPServStats.CmdReq	INT	Not used
MBAPServStats.CmdResp	INT	Not used
MBAPServStats.CmdErr	INT	Not used
MBAPServStats.Requests	INT	This counter increments each time an MBAP (port 502) request is received.
MBAPServStats.Responses	INT	This counter is incremented each time an MBAP (port 502) response message is sent.
MBAPServStats.ErrSent	INT	This counter increments each time an MBAP (port 502) sends an exception response to Client. Example: Client sent illegal Modbus Data location address.
MBAPServStats.ErrRec	INT	This counter increments each time an MBAP (port 502) receives a bad command. Example: Client sent illegal function command.
MBAPServStats.CfgErrWord	INT	Configuration Error Word - Contains a bitmap that indicates Client and server configuration errors
MBAPServStats.CurErr	INT	Not used
MBAPServStats.LastErr	INT	Not used
ClientStats.CmdReq	INT	This value is incremented each time a command request is issued.
ClientStats.CmdResp	INT	This value is incremented each time a command response is received.

Controller Tag	Data Type	Description
ClientStats.CmdErr	INT	This value is incremented each time an error message is received from a remote unit or a local error is generated for a command.
ClientStats.Requests	INT	Not used
ClientStats.Responses	INT	Not used
ClientStats.ErrSent	INT	Not used
ClientStats.ErrRec	INT	Not used
ClientStats.CfgErrWord	INT	Configuration Error Word - Contains a bitmap that indicates Client and server configuration errors
ClientStats.CurErr	INT	Most recent error code recorded for the Client
ClientStats.LastErr	INT	Previous most recent error code recorded for the Client
BlockStats.Read	INT	Total number of read blocks transferred from the module to the processor.
BlockStats.Write	INT	Total number of write blocks transferred from the processor to the module
BlockStats.Count	INT	Total number of blocks successfully parsed that were received from the processor
BlockStats.Event	INT	Total number of command event blocks received from the processor
BlockStats.Cmd	INT	Total number of command blocks received from the processor
BlockStats.Err	INT	Total number of block errors recognized by the module

### 4.3.2 Configuration Error Word

The *Configuration Error Word* contains Client and server configuration error indications, in a bit-mapped format. Specific bits in the module's *Configuration Error Word* are turned on (set to 1) to indicate various configuration errors. The *Configuration Error Word* appears in three separate *MNET.STATUS* controller tags. Since there is only one *Configuration Error Word* for the whole module, each of these tags contains exactly the same data, even though the tag name might imply otherwise. Multiple copies of the same module error data have been included in these different controller tag locations for your convenience when troubleshooting.

Bits set to 1 in the *Configuration Error Word* indicate the following errors.

Bit	Description	Hex Value
0	Reserved - not currently used	0001h
1	Reserved - not currently used	0002h
2	Reserved - not currently used	0004h
3	Reserved - not currently used	0008h
4	Invalid retry count parameter (Client only)	0010h
5	The float flag parameter is not valid. (Client or server)	0020h
6	The float start parameter is not valid. (Client or server)	0040h
7	The float offset parameter is not valid. (Client or server)	0080h
8	The ARP Timeout is not in range (ARP Timeout parameter 0 or greater than 60000 milliseconds) and will default to 5000 milliseconds. (Client only)	0100h
9	The Command Error Delay is > 300 and will default to 300. (Client only)	0200h
10	Reserved - not currently used	0400h
11	Reserved - not currently used	0800h
12	Reserved - not currently used	1000h
13	Reserved - not currently used	2000h
14	Reserved - not currently used	4000h
15	Reserved - not currently used	8000h

Combinations of errors will result in more than one bit being set in the error word. Correct any invalid data in the configuration for proper module operation. A value of zero (0) in this word indicates all bits are clear, which means that all module configuration parameters contain valid values. However, this does not mean that the configuration is valid for the user application. Make sure each parameter is set correctly for the intended application.



### 4.3.3 Client Command Errors

There are several different ways to view Client Command Errors.

- In the *MNET.STATUS.ClientStats.CurErr* and *MNET.STATUS.ClientStats.LastErr* controller tags
- On the Client status data screens in the *ProSoft Configuration Builder Diagnostics*
- At a module database location specified by the configuration's *MNET Client 0 Command Error Pointer*, if the *Command Error Pointer* is enabled. This means that the first register refers to command 1 and so on.

Word Offset	Description
1	Command 1 Error
2	Command 2 Error
3	Command 3 Error
...	...
...	...

For every command that has an error, the module automatically sets the poll delay parameter to 30 seconds. This instructs the module to wait 30 seconds until it attempts to issue the command again.

As the commands in the Client Command List are polled and executed, an error value is maintained in the module for each command. This error list can be transferred to the processor.

#### Standard Modbus Exception Code Errors

Code	Description
1	Illegal function
2	Illegal data address
3	Illegal data value
4	Failure in associated device
5	Acknowledge
6	Busy; message was rejected

#### Module Communication Error Codes

Code	Description
-2	Timeout while transmitting message
-11	Timeout waiting for response after request (same as -36)
253	Incorrect slave/server address in response
254	Incorrect function code in response
255	Invalid CRC/LRC value in response

### MNET Client Specific Errors

Code	Description
-36	MNET command response timeout (same as -11)
-37	TCP/IP connection ended before session finished

### Command List Entry Errors

Code	Description
-40	Too few parameters
-41	Invalid enable code
-42	Internal address > maximum address
-43	Invalid node address (<0 or >255)
-44	Count parameter set to 0
-45	Invalid function code
-46	Invalid swap code
-48	Could not establish a connection

**Note:** When the Client gets error -47 or -48, it uses the adjustable ARP Timeout parameter in the configuration file to set an amount of time to wait before trying again to connect to this non-existent server. This feature allows the Client to continue sending commands and polling other existing servers, while waiting for the non-existent server to appear on the network.

## 5 Reference

### *In This Chapter*

❖ Product Specifications .....	107
❖ Backplane Data Transfer.....	110
❖ Data Flow between the MVI56E-MNET Module and ControlLogix Processor .....	131
❖ Ethernet Cable Specifications .....	136
❖ Modbus Protocol Specification .....	138
❖ Using the Optional Add-On Instruction Rung Import .....	151
❖ Adding the Module to an Existing Project .....	160
❖ Using the Sample Program .....	163

### 5.1 Product Specifications

The MVI56E Modbus TCP/IP Client/Server Communication Module allows Rockwell Automation ControlLogix processors to interface easily with other Modbus compatible devices.

Compatible devices include Modicon Programmable Automation Controllers (PACs), as well as a wide variety of instruments and devices. A 5000-word register space in the module exchanges data between the processor and the Modbus TCP/IP network.

The MVI56E-MNET and MVI56E-MNETXT are functionally the same. The MVI56E-MNET is designed for standard process applications. The MVI56E-MNETXT is designed for the Logix-XT™ control platform, allowing it to operate in extreme environments and at higher operating temperatures. It has a conformal coating to protect it from harsh or caustic conditions.

### **5.1.1 General Specifications**

- Backward compatible with previous MVI56-MNET versions
- Single-slot 1756 ControlLogix backplane compatible
- 10/100 Mbps auto crossover detection Ethernet configuration and application port
- User-definable module data memory mapping of up to 5000 16-bit registers
- CIPconnect-enabled network configuration and diagnostics monitoring using ControlLogix 1756-ENxT and 1756-CNB modules and EtherNet/IP pass-through communication
- ProSoft Configuration Builder (PCB) software supported, a Windows-based graphical user interface providing simple product and network configuration
- Sample ladder logic and Add-On Instructions (AOI) are used for data transfer between module and processor
- 4-character, alpha-numeric, scrolling LED display of status and diagnostics data in plain English – no cryptic error or alarm codes to decipher
- ProSoft Discovery Service (PDS) software used to locate the module on the network and assign temporary IP address
- Personality Module - a non-volatile, industrial-grade Compact Flash (CF) card used to store network and module configuration, allowing quick in-the-field product replacement by transferring the CF card

### **5.1.2 Modbus TCP/IP Specifications**

- ProSoft Technology's Modbus TCP/IP implementation (MNET) includes both Client (Master) and server (slave) capabilities
- Modbus data types overlap in the module's memory database, so the same data can be conveniently read or written as bit-level or register-level data.
- Configurable floating-point data movement is possible, including support for Enron or Daniel<sup>®</sup> floating-point formats

#### **Modbus TCP/IP Server (Slave)**

- Supports ten independent server connections for Service Port 502 (MBAP)
- Supports ten independent server connections for Service Port 2000 (Encapsulated)
- Accepts Modbus Function Codes 1, 2, 3, 4, 5, 6, 7, 8, 15, 16, 17, 22 and 23
- Module data can be derived from other Modbus server devices on the network through the Client or from the ControlLogix processor

### Modbus TCP/IP Client (Master)

- Actively reads data from and writes data to Modbus TCP/IP devices, using MBAP or Encapsulated Modbus message formats
- Transmit Modbus Function Codes 1, 2, 3, 4, 5, 6, 7, 15, and 16
- Offers one Client connection with up to 100 commands to talk to multiple servers
- ControlLogix processor can be programmed to use special functions to control the activity on the Client by actively selecting commands to execute from the command list (Command Control) or by issuing commands directly from the ladder logic (Event Commands)

### Status Data

- Error codes, counters, and module status available from module memory through the server, through the Client, or through the ladder logic and controller tags in RSLogix™ 5000

## 5.1.3 Hardware Specifications

Specification	Description
Backplane Current Load	800 mA @ 5 Vdc 3 mA @ 24 Vdc
Operating Temperature	0°C to 60°C (32°F to 140°F)
Storage Temperature	-40°C to 85°C (-40°F to 185°F)
Shock	30 g operational 50 g non-operational Vibration: 5 g from 10 Hz to 150 Hz
Relative Humidity	5% to 95% (without condensation)
LED Indicators	Battery Status (ERR) Application Status (APP) Module Status (OK)
4-Character, Scrolling, Alpha-Numeric LED Display	Shows Module, Version, IP, Application Port Setting, Port Status, and Error Information
<b>Debug/Configuration/Application Ethernet port (E1)</b>	
Ethernet Port	10/100 Base-T, RJ45 Connector, for CAT5 cable Link and Activity LED indicators Auto-crossover cable detection
Shipped with Unit	5-foot Ethernet straight-through cable


## 5.2 Backplane Data Transfer

The MVI56E-MNET module communicates directly over the ControlLogix backplane. Data is paged between the module and the ControlLogix processor across the backplane using the module's input and output images. The update frequency of the images is determined by the scheduled scan rate defined by the user for the module and the communication load on the module. Typical update times range from 1 to 10 milliseconds.

This bi-directional transfer of data is accomplished by the module putting data in the input image to send to the processor. Data in the input image is placed in the processor's controller tags by ladder logic. The input image is set to 250 words.

Processor logic inserts data to the output image to be transferred to the module. The module's firmware program extracts the data and places it in the module's internal database. The output image is set to 248 words.


The following illustration shows the data transfer method used to move data between the ControlLogix processor, the MVI56E-MNET module and the Modbus TCP/IP Network.



All data transferred between the module and the processor over the backplane is through the input and output images. Ladder logic must be written in the ControlLogix processor to interface the input and output image data with data contained in the controller tags. All data used by the module is stored in its internal database. This database is defined as a virtual Modbus data table with addresses from 0 (40001 Modbus) to 4999 (45000 Modbus).

### Module's Internal Database Structure

5000 registers for user data



Data contained in this database is transferred in blocks, or pages, using the input and output images. ControlLogix ladder logic and the MVI56E-MNET module's program work together to coordinate these block transfers. Up to 200 words of data can be transferred from the module to the processor (read block - input image) or from the processor to the module (write block - output image) in each block transfer. The block structure of each block type depends on the data content and the data transfer function to be performed by the block. The module uses the following block identification numbers.

Block ID Range	Descriptions
-1	Null block
0	For firmware versions earlier than 2.05, this is a null block. For firmware versions 2.05 and newer, block 0 contains the same data as block 1. This feature enhances performance, especially when using less than 200 words of read/write data: <ul style="list-style-type: none"> <li>If Read Register Count in the module configuration file is set &gt; 200 words, Block ID 0 is not used.</li> <li>If Read Register Count in the module configuration file is set &gt;0 and &lt;= 200 words, Block ID contains the same data as block 1 (both read data and status data).</li> </ul>
1 to 25	Read or Write blocks
1000 to 1024	Initialize Output Data blocks
2000	Event Command block
5001 to 5006	Command Control blocks
9956	Formatted Pass-through block from function 6 or 16 with word data
9957	Formatted Pass-through block from function 6 or 16 with floating-point data
9958	Formatted Pass-through block from function 5
9959	Formatted Pass-through block from function 15
9960	Formatted Pass-through block from function 22
9961	Formatted Pass-through block from function 23
9970	Function 99 indication block
9990	Set Module IP Address block
9991	Get Module IP Address block
9996	Unformatted Pass-through block with raw Modbus message
9998	Warm-boot block
9999	Cold-boot block

These block identification codes can be broken down into two groups:

Normal data transfer blocks

- Read and Write blocks (-1 to 25)

Special function blocks

- Initialize Output Data blocks (1000 to 1024)
- Event Command block (2000)
- Command Control blocks (5001 to 5006)
- Pass-through blocks (9956 to 9961, 9970 and 9996)
- Module IP Address blocks (9990 and 9991)
- Warm-boot and Cold-boot blocks (9998 and 9999)



### 5.2.1 Normal Data Transfer Blocks

Normal data transfer includes the paging of user data from the module's internal database (registers 0 to 4999), as well as paging of status data. These data are transferred through read (input image) and write (output image) blocks.

The following topics describe the function and structure of each block.

#### Read Block

These blocks of data transfer information from the module to the ControlLogix processor.

The following table describes the structure of the input image.

**Read Block from Module to Processor**

Word Offset	Description	Length
0	Reserved	1
1	Write Block ID	1
2 to 201	Read Data	200
202	Program Scan Counter	1
203 to 208	Block Transfer Status	6
209	Product Code 1	1
210	Product Code 2	1
211	Version number	1
212 to 218	Not Used	7
219 to 221	Reserved	2
222 to 228	MNet Server Status	7
229 to 231	Reserved	2
232 to 238	MBAP Server Status	7
239 to 248	MNet Client Status	10
249	Read Block ID	1

The Read Block ID is an index value used to determine where the 200 words of data from module memory will be placed in the *ReadData[x]* controller tag array of the ControlLogix processor. Each transfer can move up to 200 words (block offsets 2 to 201) of data. In addition to moving user data, the block also contains status data for the module. The Write Block ID associated with the block requests data from the ControlLogix processor.

During normal program operation, the module sequentially sends read blocks and requests write blocks.

For example, if the application uses three read and two write blocks, the sequence will be as follows:

R1W1→R2W2→R3W1→R1W2→R2W1→R3W2→R1W1→

This sequence will continue until interrupted by other write block numbers sent by the controller or by a command request from a node on the Modbus network or operator control through the module's Configuration/Debug port.

**Status Data in the Read Block**

The following table describes in more detail the status information contained in the Read block.

Word Offset	Content	Description
202	Program Scan Count	This value is incremented each time a complete program cycle occurs in the module.
203	Read Block Count	This field contains the total number of read blocks transferred from the module to the processor.
204	Write Block Count	This field contains the total number of write blocks transferred from the processor to the module.
205	Parse Block Count	This field contains the total number of blocks successfully parsed that were received from the processor.
206	Command Event Block Count	This field contains the total number of command event blocks received from the processor.
207	Command Block Count	This field contains the total number of command blocks received from the processor.
208	Error Block Count	This field contains the total number of block errors recognized by the module.
209	Product Code 1	This register displays the first word of the product code in ASC format
210	Product Code 2	This register displays the second word of the product code in ASC format
211	Version number	This register displays the version number in decimal values. For example, if the version number is 1.51, it will display as 151.
212	Reserved	Not used
213	Reserved	Not used
214	Reserved	Not used
215	Reserved	Not used
216	Reserved	Not used
217	Reserved	Not used
218	Reserved	Not used
219	Reserved	Not used
220	Reserved	Not used
221	Reserved	Not used
222	MNet Request Count	This counter increments each time an MNet (port 2000) request is received.
223	MNet Response Count	This counter is incremented each time an MNet (port 2000) response message is sent.
224	MNet Errors Sent Count	This counter increments each time an MNet (port 2000) sends an exception response to Client. Example: Client sent illegal Modbus Data location address.
225	MNet Errors Received Count	This counter increments each time an MNet (port 2000) receives a bad command. Example: Client sent illegal function command.
226	Configuration Error Word	This word contains a bit map that indicates Client and server configuration errors.
227	Reserved	Not used
228	Reserved	Not used

Word Offset	Content	Description
229	Reserved	Not used
230	Reserved	Not used
231	Reserved	Not used
232	MBAP Request Count	This counter increments each time a MBAP (port 502) request is received.
233	MBAP Response Count	This counter is incremented each time a MBAP (port 502) response message is sent.
234	MBAP Errors Sent Count	This counter increments each time an MNet (port 502) sends an exception response to Client. Example: Client sent illegal Modbus Data location address.
235	MBAP Errors Received Count	This counter increments each time an MNet (port 502) receives a bad command. Example: Client sent illegal function command.
236	Configuration Error Word	This word contains a bitmap that indicates Client and server configuration errors.
237	Reserved	Not used
238	Reserved	Not used
239	Client Cmd Request	This value is incremented each time a command request is issued.
240	Client Cmd Response	This value is incremented each time a command response is received.
241	Client Cmd Error	This value is incremented each time an error message is received from a remote unit or a local error is generated for a command.
242	Reserved	Not used
243	Reserved	Not used
244	Reserved	Not used
245	Reserved	Not used
246	Configuration Error Word	This word contains a bitmap that indicates Client and server configuration errors.
247	Client Current Error Code	This value corresponds to the current error code for the Client.
248	Client Last Error Code	This value corresponds to the last error code recorded for the Client.
249	Read Block ID	Current Read Block ID. An initialization value of -11 will be present until module boot-up completes.

Status information transferred in the Read block can be viewed in the *MNET.STATUS* controller tag structure in the ladder logic. For more information, see the Status Data Definition (page 102).

### Write Block

These blocks of data transfer information from the ControlLogix processor to the module.

The following table describes the structure of the output image.

#### **Write Block from Processor to Module**

<b>Word Offset</b>	<b>Description</b>	<b>Length</b>
0	Write Block ID	1
1 to 200	Write Data	200
201 to 247	Spare	46
247	Select Priority Read Block	1

The Write Block ID is an index value used to determine the location in the module's database where the data will be placed. Each transfer can move up to 200 words (block offsets 1 to 200) of data.

### Select Priority Read Block (Write Block Offset 247)


**Note:** The Select Priority Read Block feature is only available for firmware versions 1.36.000 and newer.

This register allows the processor to select which read blocks will be returned from the module. If this register equals zero, the module will return all read blocks in sequential order.

If this register has a non-zero value, the module will return the read block selected, and the following one.

This feature can be used for applications that require some read blocks to be updated more frequently than other blocks.

The following illustrations show the effect of changing the value of the Select Priority Read Block register (Write Block offset 247). In the following histogram curve, the Select Priority Read Block is equal to 0.




- Local:1.O.Data[247] = Select Priority Read Block.
- Local:1.I.Data[249] = Read Block ID.

In the example above, all read blocks (1 to 10) are returned in sequential order.

### Select Priority Read Block = 5


If the ladder logic changes the value of Local:1:O.Data[247] from 0 to 5, note that the Local:1:I.Data[249] value begins to alternate between Block IDs 5 and 6 as long as Local:1:I.Data[247] stays set to 5.

5-6-5-6-5-6-5-6-...



### Select Priority Read Block = 0

After the ladder logic changes the value of Local:1:O.Data[247] from 5 to 0, then the Local:1:I.Data[249] value is updated as before, by returning all blocks 1 through 10 in a repeating sequence.




## 5.2.2 Special Function Blocks

Special function blocks are optional blocks used to request special tasks from the module.

### Initialize Output Data Blocks (1000 to 1024)

Use the *Initialize Output Data* parameter in the configuration to bring the module to a known state after a restart operation. If the *Initialize Output Data* parameter is enabled, when the module performs a restart operation, it will request blocks of output data from the *ReadData* array in the processor to initialize the Read Data area of the module's internal database.



### Block Request from Module to Processor

Word Offset	Description	Length
0	Reserved	1
1	1000 to 1024	1
2 to 248	Spare	247
249	1000 to 1024	1

Ladder logic subtracts 1000 from the value contained in word 249 to determine a block index. This block index determines which 200-word block of data will be taken from the *ReadData* array and placed in the output image to be returned to the module.

### Block Response from Processor to Module

Word Offset	Description	Length
0	1000 to 1024	1
1 to 200	Output data to preset in module.	200
201 to 247	Spare	47

### Event Command Blocks (2000)

**Note:** Event Commands are not needed for normal Modbus command list polling operations and are needed only occasionally for special circumstances.

During routine operation, the module continuously cycles through the user-defined *MNET Client 0 Command List* (page 47), examining commands in the order they are listed and sending enabled commands on the network. However, the module also has a special command priority queue, which is an internal buffer that holds commands from special function blocks until they can be sent on the network.

When one or more commands appear in the command priority queue:

- 1 The routine polling process is temporarily interrupted.
- 2 The commands in the command priority queue are executed until the queue is empty.
- 3 Then the module goes back to where it left off on the *MNET Client 0 Command List* and continues routine polling.

Event Command blocks send Modbus TCP/IP commands directly from controller tags by ladder logic to the Client command priority queue on the module. Event Commands are not placed in the module's internal database and are not part of the *MNET Client 0 Command List*.

#### **Block Request from Processor to Module**

Word Offset	Description	Length
0	<i>Block ID</i> - This word contains block identification code 2000 to indicate that the block contains a command to be executed by the Client driver.	1
1 to 4	<i>IP Address</i> - These four words contain the IP address of the destination server. Each octet value ( <b>0</b> to <b>255</b> ) of the destination server's IP address is placed in one of the four registers. For example, to reach IP address 192.168.0.100, enter the following values in words 1 to 4 → 192, 168, 0, and 100. The module will construct the normal dotted IP address from the values entered. The values entered will be ANDed with the mask 0x00ff to ensure the values are in the range of 0 to 255.	4
5	<i>Service Port</i> - This word contains the TCP service port used in the message. For example, to interface with a MBAP device, the word should contain a value of <b>502</b> . To interface with a MNET device, a value of <b>2000</b> should be used. Any value from <b>0</b> to <b>65535</b> is permitted. A value of <b>502</b> will cause a MBAP formatted message to be generated. All other values will generate an encapsulated Modbus (serial-type) message.	1
6	<i>Slave Address</i> - This word contains the Modbus node address for the message. This field should have a value from <b>1</b> to <b>247</b> .	1
7	<i>Internal DB Address</i> - This word contains the internal Modbus address in the module to use with the command. This word can contain a value from <b>0</b> to <b>4999</b> .	1
8	<i>Point Count</i> - This word contains the count parameter that determines the number of digital points or registers to associate with the command.	1
9	<i>Swap Code</i> - This parameter specifies the swap type for the data. This option is valid only for function codes 3 and 4.	1



10	<i>Modbus Function Code</i> - This word contains the Modbus function code for the command.	1
11	<i>Device Database Address</i> - This word contains the Modbus address in the server device to be associated with the command.	1
12 to 247	Spare	236

When the module receives this request block, it builds the command, places the command in the command priority queue (if the queue is not already full; maximum capacity is 100 commands), and returns a response block to tell the ladder logic whether or not the command has been successfully added to the queue.

#### Block Response from Module to Processor

Word Offset	Description
0	Reserved
1	This word contains the next write request block identification code.
2	This word contains the result of the event request. If a value of one (1) is present, the command was successfully added to the queue. If a value of zero (0) is present, no room was found in the command priority queue.
3 to 248	Spare
249	This word contains the block identification code 2000 requested by the processor.

Word 2 of the block can be used by the ladder logic to determine whether or not the command was successfully added to the command priority queue. The command will fail if the queue for the port is already full at the time when the Event Command block is received by the module.

### Controller Tags

The elements of the *MNET.UTIL.EventCmd* controller tag array contain all the values needed to build one Modbus TCP/IP command, have it sent to the module, and control the processing of the returned response block.

Controller Tag	Description
EventCmdTrigger	Set this tag to 1 to trigger the execution of the Event Command.
EventCmdPending	Temporary variable used to prevent a new Event Command block from being sent to the module until the previously sent Event Command block has been completely processed and a response block has been returned.
IPAddress	Enter the four octet IP address numbers of the target Modbus server into this array tag.
ServicePort	Enter <b>502</b> for a MBAP message or <b>2000</b> for a MNET message.
SlaveAddress	Enter the Modbus Node Address. Enter <b>0</b> , if not needed.
InternalDBAddress	Enter the database address for the Client.
PointCount	Enter the number of words or bits to be transferred by the Client.
SwapCode	Enter the swap type for the data. This function is only valid for function codes 3 and 4.
ModbusFunctionCode	Enter the Modbus function code for the command.
DeviceDBAddress	Enter the database address for the server.
EventCmdStatusReturned	Temporary variable that provides status indication of whether or not the Event Command was successfully added to the command priority queue.
EventBlockID	Temporary variable that provides the identification code number of the Block ID just executed.

### Command Control Blocks (5001 to 5006)

**Note:** Command Control is not needed for normal Modbus command list polling operations and are needed only occasionally for special circumstances.

During routine operation, the module continuously cycles through the user-defined *MNET Client 0 Command List* (page 47), examining commands in the order they are listed and sending enabled commands on the network. However, the module also has a special command priority queue, which is an internal buffer that holds commands from special function blocks until they can be sent on the network.

When one or more commands appear in the command priority queue:

- 1 The routine polling process is temporarily interrupted.
- 2 The commands in the command priority queue are executed until the queue is empty.
- 3 Then the module goes back to where it left off on the *MNET Client 0 Command List* and continues routine polling.

Like Event Command blocks, Command Control blocks place commands into the module's command priority queue. Unlike Event Commands blocks, which contain all the values needed for one command, Command Control is only used with commands already defined in the *MNET Client 0 Command List*.

Commands in the *MNET Client 0 Command List* may be either enabled for routine polling or disabled and excluded from routine polling. A disabled command has its *Enable* parameter set to **NO** (0) and is skipped during routine polling. An enabled command has its *Enable* parameter set to **YES** (1) and is sent during routine polling. However, Command Control allows any command in the predefined *MNET Client 0 Command List* to be added to the command priority queue, whether it is enabled for routine polling or not.

Command Control also gives you the option to use ladder logic to have commands from the *MNET Client 0 Command List* executed at a higher priority and out of routine order, if such an option might be required in special circumstances.

A single Command Control block request can place up to six commands from the *MNET Client 0 Command List* into the command priority queue.

**Block Request from Processor to Module**

Word Offset	Description
0	Command Control block identification code of <b>5001</b> to <b>5006</b> . The rightmost digit indicates the number of commands ( <b>1</b> to <b>6</b> ) to add to the command priority queue.
1	This word contains the Command Index for the first command to be entered into the queue.
2	This word contains the Command Index for the second command to be entered into the queue.
3	This word contains the Command Index for the third command to be entered into the queue.
4	This word contains the Command Index for the fourth command to be entered into the queue.
5	This word contains the Command Index for the fifth command to be entered into the queue.
6	This word contains the Command Index for the sixth command to be entered into the queue.
7 to 247	Spare

The last digit in the block identification code indicates the number of commands to process. For example, a block identification code of **5003** indicates that three commands are to be placed in the queue. In this case, the first three of the six available Command Indexes will be used to determine exactly which three commands will be added to the queue, and to set their order of execution.

Values to enter for the six Command Indexes range from **0** to **99** and correspond to the *MNET Client 0 Command List* entries, which are numbered from 1 to 100. To determine the Command Index value, subtract one (**1**) from the row number of the command in the *MNET Client 0 Command List*, as seen in the *Command Editor* window of *ProSoft Configuration Builder (PCB)*.

The module responds to a Command Control block request with a response block, indicating the number of commands added to the command priority queue.

**Block Response from Module to Processor**

Word Offset	Description
0	Reserved
1	This word contains the next write block identification code.
2	This word contains the number of commands in the block added to the command priority queue.
3 to 248	Spare
249	This word contains the block 5001 to 5006 requested by the processor.

### Controller Tags

The *MNET.UTIL.CmdControl* controller tag array holds all the values needed to create one Command Control block, have it sent to the module, and control the processing of the returned response block.

Controller Tag	Description
TriggerCmdCntrl	Set this tag to <b>1</b> to trigger the execution of a command after all the other parameters have been entered.
NumberOfCommands	Enter a decimal value representing the quantity of commands to be requested in the Command Control block ( <b>1</b> to <b>6</b> ).
CommandIndex[x]	Enter the <b>ROW NUMBER</b> of the command in the <i>MNET Client 0 Command List</i> in <i>Prosoft Configuration Builder</i> minus <b>1</b> . This is a six-element array. Each element holds one Command Index.
CmdsAddedToQueue	Returned decimal value representing the quantity of commands added from the <i>MNET Client 0 Command List</i> to the command priority queue by the most recent Command Control block.
CmdControlBlockID	Temporary variable that provides block ID of the Command Control block most recently processed by the module.
CmdCntrlPending	Temporary variable used to prevent a new Command Control block from being sent to the module until the previously sent Command Control block has been completely processed and a response block has been returned.

### Pass-Through Blocks (9956-9961, 9970 and 9996)

In Pass-Through mode, write messages sent to a server port are passed directly through to the processor. In this mode, the module sends special blocks to the processor when a write request is received from a Client. Ladder logic must handle the receipt of these blocks and place the enclosed data into the proper controller tags in the processor.

There are two basic modes of operation when the pass-through feature is utilized: Unformatted (code 1) and Formatted (code 2 or 3). In the unformatted mode, messages received on the server are passed directly to the processor without any processing. These unformatted blocks require more decoding than the formatted blocks.

The Modbus protocol supports control of binary output (coils - functions 5 and 15) and registers (functions 6 and 16).

Any Modbus function 5, 6, 15 or 16 commands will be passed from the server to the processor using the block identification numbers 9956 to 9961, 9970 and 9996.

### **Formatted Pass-Through Blocks**

In formatted pass-through mode, the module processes the received write request and generates a special block dependent on the function received. There are two modes of operation when the formatted pass-through mode is selected. If code 2 is utilized (no swap), the data received in the message is presented in the order expected by the processor. If code 3 is utilized (swap mode), the bytes in the data area of the message will be swapped. This selection is applied to all received write requests. The block identification code used with the request depends on the Modbus function requested.

Block ID	Modbus Function
9956	6, 16 (word type data)
9957	6, 16 (floating-point)
9958	5
9959	15
9960	22
9961	23
9970	99

### **Pass-Through Blocks 9956, 9957, 9958, 9960 or 9961 from Module to Processor**

Word Offset	Description	Length
0	0	1
1	9956, 9957, 9958, 9960 or 9961	1
2	Number of word registers in Modbus data set	1
3	Starting address for Modbus data set	1
4 to 248	Modbus data set	245
249	9956, 9957, 9958, 9960 or 9961	1

#### Pass-Through Block 9959 from Module to Processor

Word Offset	Description	Length
0	0	1
1	9959	1
2	Number of word registers in Modbus data set	1
3	Starting word address for Modbus data set	1
4 to 53	Modbus data set	50
54 to 103	Bit mask for the data set. Each bit to be considered with the data set will have a value of 1 in the mask. Bits to ignore in the data set will have a value of 0 in the mask.	50
104 to 248	Spare data area	145
249	9959	1

#### Pass-Through Block 9970 from Module to Processor

Word Offset	Description	Length
0	0	1
1	9970	1
2	1	1
3	0	1
4 to 248	Spare data area	245
249	9996	1

The ladder logic should copy and parse the received message and control the processor as expected by the Client device. The processor responds to the formatted pass-through blocks with a write block.

#### Response Blocks 9956, 9957, 9958, 9959, 9960, 9961, or 9970 from Processor to Module

Word Offset	Description	Length
0	9956, 9957, 9958, 9959, 9960, 9961, or 9970	1
1 to 249	Spare data area	247

### Unformatted Pass-Through Blocks

When the unformatted pass-through mode (code 1) is selected, information is passed from the module to the processor with a block identification code of 9996. Word 2 of this block contains the length of the message, and the message starts at word 3. Other controller tags are required to store the controlled values contained in these messages.

#### Pass-Through Block 9996 from Module to Processor

Word Offset	Description	Length
0	0	1
1	9996	1
2	Number of bytes in Modbus msg	1
3	Reserved (always 0)	1
4 to 248	Modbus message received	245
249	9996	1

The ladder logic should copy and parse the received message and control the processor as expected by the Client device. The processor responds to the pass-through block with a write block.

#### Response Block 9996 from Processor to Module

Word Offset	Description	Length
0	9996	1
1 to 247	Spare	247

This informs the module that the command has been processed and can be cleared from the pass-through queue.



Set Module IP Address Block (9990)

**Block Request from Processor to Module**

Word Offset	Description	Length
0	9990	1
1	First digit of dotted IP address	1
2	Second digit of dotted IP address	1
3	Third digit of dotted IP address	1
4	Last digit of dotted IP address	1
5 to 247	Reserved	243

**Block Response from Module to Processor**

Word Offset	Description	Length
0	0	1
1	Write Block ID	1
2	First digit of dotted IP address	1
3	Second digit of dotted IP address	1
4	Third digit of dotted IP address	1
5	Last digit of dotted IP address	1
6 to 248	Spare data area	243
249	9990	1

Get Module IP Address Block (9991)

**Block Request from Processor to Module**

Word Offset	Description	Length
0	9991	1
1 to 247	Spare data area	247

**Block Response from Module to Processor**

Word Offset	Description	Length
0	0	1
1	Write Block ID	1
2	First digit of dotted IP address	1
3	Second digit of dotted IP address	1
4	Third digit of dotted IP address	1
5	Last digit of dotted IP address	1
6 to 248	Spare data area	243
249	9991	1

### Warm Boot Block (9998)

This block is sent from the ControlLogix processor to the module (output image) when the module is required to perform a warm-boot (software reset) operation. This block is commonly sent to the module any time configuration data modifications are made in the controller tags data area. This will cause the module to read the new configuration information and to restart.

#### **Block Request from Processor to Module**

Word Offset	Description	Length
0	9998	1
1 to 247	Spare	247

### Cold Boot Block (9999)


This block is sent from the ControlLogix processor to the module (output image) when the module is required to perform the cold boot (hardware reset) operation. This block is sent to the module when a hardware problem is detected by the ladder logic that requires a hardware reset.

#### **Block Request from Processor to Module**

Word Offset	Description	Length
0	9999	1
1 to 247	Spare	247


### 5.3 Data Flow between the MVI56E-MNET Module and ControlLogix Processor

The following topics describe the flow of data between the two pieces of hardware (ControlLogix processor and MVI56E-MNET module) and other nodes on the Modbus TCP/IP network under the module's different operating modes. The module contains a server and a Client. The server accepts TCP/IP connections on service ports 502 (MBAP) (10 server connections) and 2000 (MNET) (10 server connections). The Client can generate either MBAP or MNET requests dependent on the service port selected in the command.



### 5.3.1 Server Driver


The server driver allows the MVI56E-MNET module to respond to data read and write commands issued by Clients on the Modbus TCP/IP network. The following illustration describes the flow of data into and out of the module.



- 1 The server driver receives the configuration information from the configuration file on the Personality Module (compact flash card), and the module initializes the server.
- 2 A host device, such as a Modicon PLC or an HMI application, issues a read or write command to the module's node address. The server driver validates the message before accepting it into the module. If the message is considered invalid, an error response is returned to the originating Client node.
- 3 After the module accepts the command, the module processes the data contained in the command.  
If the command is a read command, the data is read out of the database and a response message is built.  
If the command is a write command, the data is written directly into the database and a response message is built.  
If the command is a write command and the pass-through feature is utilized, the write message is transferred to the processor ladder logic and is not written directly into the module's database, unless it is returned as a change in the output image that overwrites data in the *WriteData* area as a result of such ladder logic processing.
- 4 After the data processing has been completed in Step 3, a response is issued to the originating Client node.


Counters are available in the Status Block that permit the ladder logic program to determine the level of activity of the server driver.

An exception to normal processing is when the pass-through mode is implemented. In this mode, all write requests are passed directly to the processor and are not placed in the database. This permits direct, remote control of the processor without changes in the intermediate database. This mode is especially useful for Client devices that do not send both states of control. For example, a SCADA system may only send a SET command to a digital control point and never send a CLEAR command to that same digital point address because it expects the processor logic to reset the control bit. Pass-through must be used to simulate this mode. The following illustration shows the data flow for a server port with pass-through enabled.



### 5.3.2 Client Driver

In the Client driver, the MVI56E-MNET module issues read or write commands to servers on the Modbus TCP/IP network. The commands originate either from the module's user-configured *Client 0 Command List*, or directly from the processor as Event Commands. The commands from the *Client 0 Command List* are executed either via routine polling or as a result of special Command Control block requests from the processor. The following flowchart describes the flow of data into and out of the module.



- 1 The Client driver obtains configuration data when the module restarts. This includes the timeout parameters and the Command List. These values are used by the driver to determine the type of commands to be issued to servers on the Modbus TCP/IP network.
- 2 When configured, the Client driver begins transmitting read and/or write commands to servers on the network. The data for write commands is obtained from the module's internal database.
- 3 Assuming successful processing by the server specified in the command, a response message is received into the Client driver for processing.

- 4 Data received from the server is passed into the module's internal database, if the command was a read command. Status information is routinely returned to the processor in the input images.
- 5 Special functions, such as Event Commands and Command Control options, can be generated by the processor and sent to the Client driver for action.

#### Client Command List

In order for the Client to function, the module's *MNET Client x Command List* must be defined in the configuration. This list contains up to 100 individual entries, with each entry containing the information required to construct a valid command. This includes the following:

- Command enable mode
  - (0) disabled
  - (1) continuous
  - (2) conditional
- IP address and service port to connect to on the remote server
- Slave Node Address
- Command Type - Read or Write up to 100 words per command
- Database Source and Destination Register Address - Determines where data will be placed and/or obtained
- Count - Selects the number of words to be transferred - 1 to 100
- Poll Delay - 1/10<sup>th</sup> seconds

For information on troubleshooting commands, see Client Command Errors (page 105).

5.4 Ethernet Cable Specifications

The recommended cable is Category 5 or better. A Category 5 cable has four twisted pairs of wires, which are color-coded and cannot be swapped. The module uses only two of the four pairs.


The Ethernet ports on the module are Auto-Sensing. You can use either a standard Ethernet straight-through cable or a crossover cable when connecting the module to an Ethernet hub, a 10/100 Base-T Ethernet switch, or directly to a PC. The module will detect the cable type and use the appropriate pins to send and receive Ethernet signals.

Ethernet cabling is like U.S. telephone cables, except that it has eight conductors. Some hubs have one input that can accept either a straight-through or crossover cable, depending on a switch position. In this case, you must ensure that the switch position and cable type agree.

Refer to Ethernet cable configuration (page 136) for a diagram of how to configure Ethernet cable.

5.4.1 Ethernet Cable Configuration

**Note:** The standard connector view shown is color-coded for a straight-through cable.

Crossover cable			Straight- through cable	
RJ-45 PIN	RJ-45 PIN		RJ-45 PIN	RJ-45 PIN
1 Rx+	3 Tx+		1 Rx+	1 Tx+
2 Rx-	6 Tx-		2 Rx-	2 Tx-
3 Tx+	1 Rx+		3 Tx+	3 Rx+
6 Tx-	2 Rx-		6 Tx-	6 Rx-



### **5.4.2 Ethernet Performance**

Ethernet performance on the MVI56E-MNET module can affect the operation of the MNET application ports in the following ways.

- Accessing the web interface (refreshing the page, downloading files, and so on) may affect MNET performance
- High Ethernet traffic may impact MNET performance (consider CIPconnect (page 64) for these applications and disconnect the module Ethernet port from the network).

## 5.5 Modbus Protocol Specification

The following pages give additional reference information regarding the Modbus protocol commands supported by the MVI56E-MNET.

### 5.5.1 *About the MODBUS TCP/IP Protocol*

MODBUS is a widely used protocol originally developed by Modicon in 1978. Since that time, the protocol has been adopted as a standard throughout the automation industry.

The original MODBUS specification uses a serial connection to communicate commands and data between Client and server devices on a network. Later enhancements to the protocol allow communication over Ethernet networks using TCP/IP as a "wrapper" for the MODBUS protocol. This protocol is known as MODBUS TCP/IP.

MODBUS TCP/IP is a Client/server protocol. The Client establishes a connection to the remote server. When the connection is established, the Client sends the MODBUS TCP/IP commands to the server. The MVI56E-MNET module works both as a Client and as a server.

Aside from the benefits of Ethernet versus serial communications (including performance, distance, and flexibility) for industrial networks, the MODBUS TCP/IP protocol allows for remote administration and control of devices over a TCP/IP network. The efficiency, scalability, and low cost of a MODBUS TCP/IP network make this an ideal solution for industrial applications.

The MVI56E-MNET module acts as an input/output module between devices on a MODBUS TCP/IP network and the Rockwell Automation backplane. The module uses an internal database to pass data and commands between the processor and the Client and server devices on the MODBUS TCP/IP network.

### 5.5.2 Read Coil Status (Function Code 01)

#### Query

This function allows the user to obtain the ON/OFF status of logic coils used to control discrete outputs from the addressed server only. Broadcast mode is not supported with this function code. In addition to the server address and function fields, the message requires that the information field contain the initial coil address to be read (Starting Address) and the number of locations that will be interrogated to obtain status data.

The addressing allows up to 2000 coils to be obtained at each request; however, the specific server device may have restrictions that lower the maximum quantity. The coils are numbered from zero; (coil number 1 = zero, coil number 2 = one, coil number 3 = two, and so on).

The following table is a sample read output status request to read coils 0020 to 0056 from server device number 11.

Adr	Func	Data Start Pt Hi	Data Start Pt Lo	Data # Of Pts Ho	Data # Of Pts Lo	Error Check Field
11	01	00	13	00	25	CRC

#### Response

An example response to Read Coil Status is as shown in Figure C2. The data is packed one bit for each coil. The response includes the server address, function code, quantity of data characters, the data characters, and error checking. Data will be packed with one bit for each coil (1 = ON, 0 = OFF). The low order bit of the first character contains the addressed coil, and the remainder follow. For coil quantities that are not even multiples of eight, the last characters will be filled in with zeros at high order end. The quantity of data characters is always specified as quantity of RTU characters, that is, the number is the same whether RTU or ASCII is used.

Because the server interface device is serviced at the end of a controller's scan, data will reflect coil status at the end of the scan. Some servers will limit the quantity of coils provided each scan; thus, for large coil quantities, multiple PC transactions must be made using coil status from sequential scans.

Adr	Func	Byte Count	Data Coil Status 20 to 27	Data Coil Status 28 to 35	Data Coil Status 36 to 43	Data Coil Status 44 to 51	Data Coil Status 52 to 56	Error Check Field
11	01	05	CD	6B	B2	OE	1B	CRC

The status of coils 20 to 27 is shown as CD(HEX) = 1100 1101 (Binary). Reading left to right, this shows that coils 27, 26, 23, 22, and 20 are all on. The other coil data bytes are decoded similarly. Due to the quantity of coil statuses requested, the last data field, which is shown 1B (HEX) = 0001 1011 (Binary), contains the status of only 5 coils (52 to 56) instead of 8 coils. The 3 left most bits are provided as zeros to fill the 8-bit format.

### 5.5.3 Read Input Status (Function Code 02)

#### Query

This function allows the user to obtain the ON/OFF status of discrete inputs in the addressed server. PC Broadcast mode is not supported with this function code. In addition to the server address and function fields, the message requires that the information field contain the initial input address to be read (Starting Address) and the number of locations that will be interrogated to obtain status data.

The addressing allows up to 2000 inputs to be obtained at each request; however, the specific server device may have restrictions that lower the maximum quantity. The inputs are numbered from zero; (input 10001 = zero, input 10002 = one, input 10003 = two, and so on, for a 584).

The following table is a sample read input status request to read inputs 10197 to 10218 from server number 11.

Adr	Func	Data Start Pt Hi	Data Start Pt Lo	Data #of Pts Hi	Data #of Pts Lo	Error Check Field
11	02	00	C4	00	16	CRC

#### Response

An example response to Read Input Status is as shown in Figure C4. The data is packed one bit for each input. The response includes the server address, function code, quantity of data characters, the data characters, and error checking. Data will be packed with one bit for each input (1=ON, 0=OFF). The lower order bit of the first character contains the addressed input, and the remainder follow. For input quantities that are not even multiples of eight, the last characters will be filled in with zeros at high order end. The quantity of data characters is always specified as a quantity of RTU characters, that is, the number is the same whether RTU or ASCII is used.

Because the server interface device is serviced at the end of a controller's scan, data will reflect input status at the end of the scan. Some servers will limit the quantity of inputs provided each scan; thus, for large coil quantities, multiple PC transactions must be made using coil status for sequential scans.

Adr	Func	Byte Count	Data Discrete Input 10197 to 10204	Data Discrete Input 10205 to 10212	Data Discrete Input 10213 to 10218	Error Check Field
11	02	03	AC	DB	35	CRC

The status of inputs 10197 to 10204 is shown as AC (HEX) = 10101 1100 (binary). Reading left to right, this shows that inputs 10204, 10202, and 10199 are all on. The other input data bytes are decoded similarly.

Due to the quantity of input statuses requested, the last data field which is shown as 35 HEX = 0011 0101 (binary) contains the status of only 6 inputs (10213 to 10218) instead of 8 inputs. The two left-most bits are provided as zeros to fill the 8-bit format.

### 5.5.4 Read Holding Registers (Function Code 03)

#### Query

Read Holding Registers (03) allows the user to obtain the binary contents of holding registers 4xxxx in the addressed server. The registers can store the numerical values of associated timers and counters which can be driven to external devices. The addressing allows up to 125 registers to be obtained at each request; however, the specific server device may have restriction that lower this maximum quantity. The registers are numbered from zero (40001 = zero, 40002 = one, and so on). The broadcast mode is not allowed.

The example below reads registers 40108 through 40110 from server 584 number 11.

Adr	Func	Data Start Reg Hi	Data Start Reg Lo	Data #of Regs Hi	Data #of Regs Lo	Error Check Field
11	03	00	6B	00	03	CRC

#### Response

The addressed server responds with its address and the function code, followed by the information field. The information field contains 1 byte describing the quantity of data bytes to be returned. The contents of the registers requested (DATA) are two bytes each, with the binary content right justified within each pair of characters. The first byte includes the high order bits and the second, the low order bits.

Because the server interface device is normally serviced at the end of the controller's scan, the data will reflect the register content at the end of the scan. Some servers will limit the quantity of register content provided each scan; thus for large register quantities, multiple transmissions will be made using register content from sequential scans.

In the example below, the registers 40108 to 40110 have the decimal contents 555, 0, and 100 respectively.

Adr	Func	ByteCnt	Hi Data	Lo Data	Hi Data	Lo Data	Hi Data	Lo Data	Error Check Field
11	03	06	02	2B	00	00	00	64	CRC

### 5.5.5 Read Input Registers (Function Code 04)

#### Query

Function code 04 obtains the contents of the controller's input registers at addresses 3xxxx. These locations receive their values from devices connected to the I/O structure and can only be referenced, not altered from within the controller. The addressing allows up to 125 registers to be obtained at each request; however, the specific server device may have restrictions that lower this maximum quantity. The registers are numbered for zero (30001 = zero, 30002 = one, and so on). Broadcast mode is not allowed.

The example below requests the contents of register 3009 in server number 11.

Adr	Func	Data Start Reg Hi	Data Start Reg Lo	Data #of Regs Hi	Data #of Regs Lo	Error Check Field
11	04	00	08	00	01	CRC

#### Response

The addressed server responds with its address and the function code followed by the information field. The information field contains 1 byte describing the quantity of data bytes to be returned. The contents of the registers requested (DATA) are 2 bytes each, with the binary content right justified within each pair of characters. The first byte includes the high order bits and the second, the low order bits.

Because the server interface is normally serviced at the end of the controller's scan, the data will reflect the register content at the end of the scan. Each PC will limit the quantity of register contents provided each scan; thus for large register quantities, multiple PC scans will be required, and the data provided will be from sequential scans.

In the example below the register 3009 contains the decimal value 0.

Adr	Func	Byte Count	Data Input Reg Hi	Data Input Reg Lo	Error Check Field
11	04	02	00	00	E9

### 5.5.6 Force Single Coil (Function Code 05)

#### Query

This message forces a single coil either ON or OFF. Any coil that exists within the controller can be forced to either state (ON or OFF). However, because the controller is actively scanning, unless the coil is disabled, the controller can also alter the state of the coil. Coils are numbered from zero (coil 0001 = zero, coil 0002 = one, and so on). The data value 65,280 (FF00 HEX) will set the coil ON and the value zero will turn it OFF; all other values are illegal and will not affect that coil.

The use of server address 00 (Broadcast Mode) will force all attached servers to modify the desired coil.

**Note:** Functions 5, 6, 15, and 16 are the only messages that will be recognized as valid for broadcast.

The example below is a request to server number 11 to turn ON coil 0173.

Adr	Func	Data Coil # Hi	Data Coil # Lo	Data On/off Ind	Data	Error Check Field
11	05	00	AC	FF	00	CRC

#### Response

The normal response to the Command Request is to re-transmit the message as received after the coil state has been altered.

Adr	Func	Data Coil # Hi	Data Coil # Lo	Data On/ Off	Data	Error Check Field
11	05	00	AC	FF	00	CRC

The forcing of a coil via MODBUS function 5 will be accomplished regardless of whether the addressed coil is disabled or not (*In ProSoft products, the coil is only affected if the necessary ladder logic is implemented*).

**Note:** The Modbus protocol does not include standard functions for testing or changing the DISABLE state of discrete inputs or outputs. Where applicable, this may be accomplished via device specific Program commands (*In ProSoft products, this is only accomplished through ladder logic programming*).

Coils that are reprogrammed in the controller logic program are not automatically cleared upon power up. Thus, if such a coil is set ON by function Code 5 and (even months later), an output is connected to that coil, the output will be "hot".

### 5.5.7 Preset Single Register (Function Code 06)

#### Query

Function (06) allows the user to modify the contents of a holding register. Any holding register that exists within the controller can have its contents changed by this message. However, because the controller is actively scanning, it also can alter the content of any holding register at any time. The values are provided in binary up to the maximum capacity of the controller unused high order bits must be set to zero. When used with server address zero (Broadcast mode) all server controllers will load the specified register with the contents specified.

**Note** Functions 5, 6, 15, and 16 are the only messages that will be recognized as valid for broadcast.

Adr	Func	Data Start Reg Hi	Data Start Reg Lo	Data #of Regs Hi	Data #of Regs Lo	Error Check Field
11	06	00	01	00	03	CRC

#### Response

The response to a preset single register request is to re-transmit the query message after the register has been altered.

Adr	Func	Data Reg Hi	Data Reg Lo	Data Input Reg Hi	Data Input Reg Lo	Error Check Field
11	06	00	01	00	03	CRC

### 5.5.8 Read Exception Status(Function Code 7)

This function code is used to read the contents of eight Exception status outputs in a remote device. Function code 7 provides a method for accessing this information, because the Exception Output references are known (no output reference is needed in the function). The normal response contains the status of the eight Exception Status outputs. The outputs are packed into one data byte, with one bit per output. The status of the lowest output reference is contained in the least significant bit of the byte.



### 5.5.9 Diagnostics (Function Code 08)

MODBUS function code 08 provides a series of tests for checking the communication system between a Client device and a server, or for checking various internal error conditions within a server.

The function uses a two-byte sub-function code field in the query to define the type of test to be performed. The server echoes both the function code and sub-function code in a normal response. Some of the diagnostics cause data to be returned from the remote device in the data field of a normal response.

In general, issuing a diagnostic function to a remote device does not affect the running of the user program in the remote device. Device memory bit and register data addresses are not accessed by the diagnostics. However, certain functions can optionally reset error counters in some remote devices.

A server device can, however, be forced into 'Listen Only Mode' in which it will monitor the messages on the communications system but not respond to them. This can affect the outcome of your application program if it depends upon any further exchange of data with the remote device. Generally, the mode is forced to remove a malfunctioning remote device from the communications system.

#### Sub-function Codes Supported

Only Sub-function 00 is supported by the MVI56E-MNET module.

#### 00 Return Query Data

The data passed in the request data field is to be returned (looped back) in the response. The entire response message should be identical to the request.


Sub-function	Data Field (Request)	Data Field (Response)
00 00	Any	Echo Request Data

#### Example and State Diagram

Here is an example of a request to remote device to Return Query Data. This uses a sub-function code of zero (00 00 hex in the two-byte field). The data to be returned is sent in the two-byte data field (A5 37 hex).

Request		Response	
Field Name	(Hex)	Field Name	(Hex)
Function	08	Function	08
Sub-function Hi	00	Sub-function Hi	00
Sub-function Lo	00	Sub-function Lo	00
Data Hi	A5	Data Hi	A5
Data Lo	37	Data Lo	27

The data fields in responses to other kinds of queries could contain error counts or other data requested by the sub-function code.



### 5.5.10 Force Multiple Coils (Function Code 15)

#### Query

This message forces each coil in a consecutive block of coils to a desired ON or OFF state. Any coil that exists within the controller can be forced to either state (ON or OFF). However, because the controller is actively scanning, unless the coils are disabled, the controller can also alter the state of the coil. Coils are numbered from zero (coil 00001 = zero, coil 00002 = one, and so on). The desired status of each coil is packed in the data field, one bit for each coil (1= ON, 0= OFF). The use of server address 0 (Broadcast Mode) will force all attached servers to modify the desired coils.

**Note:** Functions 5, 6, 15, and 16 are the only messages (other than Loopback Diagnostic Test) that will be recognized as valid for broadcast.

The following example forces 10 coils starting at address 20 (13 HEX). The two data fields, CD =1100 and 00 = 0000 000, indicate that coils 27, 26, 23, 22, and 20 are to be forced on.

Adr	Func	Hi Add	Lo Add	Quantity	Byte Cnt	Data Coil Status 20 to 27	Data Coil Status 28 to 29	Error Check Field
11	0F	00	13	00	0A	02	CD	00 CRC

#### Response

The normal response will be an echo of the server address, function code, starting address, and quantity of coils forced.

Adr	Func	Hi Addr	Lo Addr	Quantity	Error Check Field
11	0F	00	13	00	0A CRC

The writing of coils via Modbus function 15 will be accomplished regardless of whether the addressed coils are disabled or not.

Coils that are unprogrammed in the controller logic program are not automatically cleared upon power up. Thus, if such a coil is set ON by function code 15 and (even months later) an output is connected to that coil, the output will be hot.

### 5.5.11 Preset Multiple Registers (Function Code 16)

#### Query

Holding registers existing within the controller can have their contents changed by this message (a maximum of 60 registers). However, because the controller is actively scanning, it also can alter the content of any holding register at any time. The values are provided in binary up to the maximum capacity of the controller (16-bit for the 184/384 and 584); unused high order bits must be set to zero.

**Note:** Function codes 5, 6, 15, and 16 are the only messages that will be recognized as valid for broadcast.

Adr	Func	Hi Add	Lo Add	Quantity		Byte Cnt	Hi Data	Lo Data	Hi Data	Lo Data	Error Check Field
11	10	00	87	00	02	04	00	0A	01	02	CRC

#### Response

The normal response to a function 16 query is to echo the address, function code, starting address and number of registers to be loaded.

Adr	Func	Hi Addr	Lo Addr	Quantity		Error Check Field
11	10	00	87	00	02	56

### 5.5.12 Modbus Exception Responses

When a Modbus Client sends a request to a server device, it expects a normal response. One of four possible events can occur from the Client's query:

- If the server device receives the request without a communication error, and can handle the query normally, it returns a normal response.
- If the server does not receive the request due to a communication error, no response is returned. The Client program will eventually process a timeout condition for the request.
- If the server receives the request, but detects a communication error (parity, LRC, CRC, ...), no response is returned. The Client program will eventually process a timeout condition for the request.
- If the server receives the request without a communication error, but cannot handle it (for example, if the request is to read a non-existent output or register), the server will return an exception response informing the Client of the nature of the error.

The exception response message has two fields that differentiate it from a normal response:

**Function Code Field:** In a normal response, the server echoes the function code of the original request in the function code field of the response. All function codes have a most-significant bit (MSB) of 0 (their values are all below 80 hexadecimal). In an exception response, the server sets the MSB of the function code to 1. This makes the function code value in an exception response exactly 80 hexadecimal higher than the value would be for a normal response.

With the function code's MSB set, the Client's application program can recognize the exception response and can examine the data field for the exception code.

**Data Field:** In a normal response, the server may return data or statistics in the data field (any information that was requested in the request). In an exception response, the server returns an exception code in the data field. This defines the server condition that caused the exception.

The following table shows an example of a Client request and server exception response.

Request		Response	
Field Name	(Hex)	Field Name	(Hex)
Function	01	Function	81
Starting Address Hi	04	Exception Code	02
Starting Address Lo	A1		
Quantity of Outputs Hi	00		
Quantity of Outputs Lo	01		

In this example, the Client addresses a request to server device. The function code (01) is for a Read Output Status operation. It requests the status of the output at address 1245 (04A1 hex). Note that only that one output is to be read, as specified by the number of outputs field (0001).

If the output address is non-existent in the server device, the server will return the exception response with the exception code shown (02). This specifies an illegal data address for the server.

### Modbus Exception Codes

Code	Name	Meaning
01	Illegal Function	The function code received in the query is not an allowable action for the server. This may be because the function code is only applicable to newer devices, and was not implemented in the unit selected. It could also indicate that the server is in the wrong state to process a request of this type, for example because it is unconfigured and is being asked to return register values.
02	Illegal Data Address	The data address received in the query is not an allowable address for the server. More specifically, the combination of reference number and transfer length is invalid. For a controller with 100 registers, a request with offset 96 and length 4 would succeed; a request with offset 96 and length 5 will generate exception 02.
03	Illegal Data Value	A value contained in the query data field is not an allowable value for server. This indicates a fault in the structure of the remainder of a complex request, such as that the implied length is incorrect. It specifically does not mean that a data item submitted for storage in a register has a value outside the expectation of the application program, because the Modbus protocol is unaware of the significance of any particular value of any particular register.
04	Slave Device Failure	An unrecoverable error occurred while the server was attempting to perform the requested action.
05	Acknowledge	Specialized use in conjunction with programming commands. The server has accepted the request and is processing it, but a long duration of time will be required to do so. This response is returned to prevent a timeout error from occurring in the Client. The Client can next issue a poll program complete message to determine if processing is completed.
06	Slave Device Busy	Specialized use in conjunction with programming commands. The server is engaged in processing a long-duration program command. The Client should retransmit the message later when the server is free.
08	Memory Parity Error	Specialized use in conjunction with function codes 20 and 21 and reference type 6, to indicate that the extended file area failed to pass a consistency check. The server attempted to read record file, but detected a parity error in the memory. The Client can retry the request, but service may be required on the server device.
0a	Gateway Path Unavailable	Specialized use in conjunction with gateways, indicates that the gateway was unable to allocate an internal communication path from the input port to the output port for processing the request. Usually means that the gateway is misconfigured or overloaded.
0b	Gateway Target Device Failed To Respond	Specialized use in conjunction with gateways, indicates that no response was obtained from the target device. Usually means that the device is not present on the network.

## 5.6 Using the Optional Add-On Instruction Rung Import

### 5.6.1 Before You Begin

- Make sure that you have installed RSLogix 5000 version 16 (or later).
- Download the Optional Add-On file *MVI56EMNET\_Optional\_AddOn\_Rung\_v1\_0.L5X* from [www.prosoft-technology.com](http://www.prosoft-technology.com) or copy it from the *ProSoft Solutions DVD*.
- Save a copy in a folder in your PC.

### 5.6.2 Overview

The Optional Add-On Instruction Rung Import contains optional logic for MVI56E-MNET applications to perform the following tasks.

- **Read/Write Ethernet Configuration**  
Allows the processor to read or write the module IP address, netmask and gateway values.


**Note:** This is an optional feature. You can perform the same task through PCB (ProSoft Configuration Builder). Even if your PC is in a different network group you can still access the module through PCB by setting a temporary IP address.

- **Read/Write Module Clock Value**  
Allows the processor to read and write the module clock settings. The module clock stores the last time that the Ethernet configuration was changed. The date and time of the last Ethernet configuration change is displayed in the scrolling LED during module power up.


**Important:** The Optional Add-On Instruction only supports the two features listed above. You must use the sample ladder logic for all other features including backplane transfer of Modbus TCP/IP data.

### 5.6.3 Installing the Rung Import with Optional Add-On Instruction

- 1 Right-click an empty rung in the main routine of your existing ladder logic and choose **IMPORT RUNG**.




- 2 Navigate to the folder where you saved MVI56EMNET\_Optional\_AddOn\_Rung\_v1\_0.L5X and select the file.







In the *Import Configuration* window, click **OK**.




The Optional Add-On Instruction will now be visible in the ladder logic. Observe that the procedure has also imported data types and controller tags associated with the Optional Add-On Instruction.




You will notice that new tags have been imported: four *Message* tags, *MVI56MNETClock* and *MVI56MNETEthernet* tags.



- 3 In the Add-On Instruction, click the [...] button next to each *MSG* tag to open the *Message Configuration* tag.
- 4 Click the **COMMUNICATION** tab and click the **BROWSE** button as follows.



- 5 Select the module to configure the message path.



### 5.6.4 Reading the Ethernet Settings from the Module

Expand the *MVI56MNETEthernet* controller tag and move a value of 1 to *MVI56MNETEthernet.Read*.

[-] MVI56MNETEthernet	{...}
[-] MVI56MNETEthernet.Read	1
[-] MVI56MNETEthernet.Write	0
[-] MVI56MNETEthernet.Config	{...}
[-] MVI56MNETEthernet.Config.IP	{...}
+ MVI56MNETEthernet.Config.IP[0]	0
+ MVI56MNETEthernet.Config.IP[1]	0
+ MVI56MNETEthernet.Config.IP[2]	0
+ MVI56MNETEthernet.Config.IP[3]	0
[-] MVI56MNETEthernet.Config.Netmask	{...}
+ MVI56MNETEthernet.Config.Netmask[0]	0
+ MVI56MNETEthernet.Config.Netmask[1]	0
+ MVI56MNETEthernet.Config.Netmask[2]	0
+ MVI56MNETEthernet.Config.Netmask[3]	0
[-] MVI56MNETEthernet.Config.Gateway	{...}
+ MVI56MNETEthernet.Config.Gateway[0]	0
+ MVI56MNETEthernet.Config.Gateway[1]	0
+ MVI56MNETEthernet.Config.Gateway[2]	0
+ MVI56MNETEthernet.Config.Gateway[3]	0

The bit will be automatically reset and the current Ethernet settings will be copied to *MVI56MNETEthernet* controller tag as follows.

[-] MVI56MNETEthernet	{...}
[-] MVI56MNETEthernet.Read	0
[-] MVI56MNETEthernet.Write	0
[-] MVI56MNETEthernet.Config	{...}
[-] MVI56MNETEthernet.Config.IP	{...}
+ MVI56MNETEthernet.Config.IP[0]	105
+ MVI56MNETEthernet.Config.IP[1]	102
+ MVI56MNETEthernet.Config.IP[2]	0
+ MVI56MNETEthernet.Config.IP[3]	12
[-] MVI56MNETEthernet.Config.Netmask	{...}
+ MVI56MNETEthernet.Config.Netmask[0]	255
+ MVI56MNETEthernet.Config.Netmask[1]	255
+ MVI56MNETEthernet.Config.Netmask[2]	255
+ MVI56MNETEthernet.Config.Netmask[3]	0
[-] MVI56MNETEthernet.Config.Gateway	{...}
+ MVI56MNETEthernet.Config.Gateway[0]	192
+ MVI56MNETEthernet.Config.Gateway[1]	168
+ MVI56MNETEthernet.Config.Gateway[2]	0
+ MVI56MNETEthernet.Config.Gateway[3]	1

To check the status of the message, refer to the *ReadEthernetMSG* tag.

[-] ReadEthernetMSG	{...}
+ ReadEthernetMSG.Flags	16#0200
[-] ReadEthernetMSG.EW	0
[-] ReadEthernetMSG.ER	0
[-] ReadEthernetMSG.DN	0
[-] ReadEthernetMSG.ST	0
[-] ReadEthernetMSG.EN	0
[-] ReadEthernetMSG.TO	0
[-] ReadEthernetMSG.EN_CC	1
+ ReadEthernetMSG.ERR	16#0000
+ ReadEthernetMSG.EXERR	16#0000_0000
+ ReadEthernetMSG.ERR_SRC	0
+ ReadEthernetMSG.DN_LEN	0
+ ReadEthernetMSG.REQ_LEN	0

### 5.6.5 Writing the Ethernet Settings to the Module

Expand the *MVI56EMNETEthernet* controller tag.

Set the new Ethernet configuration in *MVI56EMNETEthernet.Config*:

Move a value of 1 to *MVI56MNETEthernet.Write*.

[-] MVI56EMNETEthernet	{...}
[-] MVI56EMNETEthernet.Read	0
[-] MVI56EMNETEthernet.Write	1
[-] MVI56EMNETEthernet.Config	{...}
[-] MVI56EMNETEthernet.Config.IP	{...}
+ MVI56EMNETEthernet.Config.IP[0]	105
+ MVI56EMNETEthernet.Config.IP[1]	102
+ MVI56EMNETEthernet.Config.IP[2]	0
+ MVI56EMNETEthernet.Config.IP[3]	12
[-] MVI56EMNETEthernet.Config.Netmask	{...}
+ MVI56EMNETEthernet.Config.Netmask[0]	255
+ MVI56EMNETEthernet.Config.Netmask[1]	255
+ MVI56EMNETEthernet.Config.Netmask[2]	255
+ MVI56EMNETEthernet.Config.Netmask[3]	0
[-] MVI56EMNETEthernet.Config.Gateway	{...}
+ MVI56EMNETEthernet.Config.Gateway[0]	192
+ MVI56EMNETEthernet.Config.Gateway[1]	168
+ MVI56EMNETEthernet.Config.Gateway[2]	0
+ MVI56EMNETEthernet.Config.Gateway[3]	1

After the message is executed, the *MVI56MNETEthernet.Write* bit resets to 0.

[-] MVI56EMNETEthernet	{...}
[-] MVI56EMNETEthernet.Read	0
[-] MVI56EMNETEthernet.Write	0
[-] MVI56EMNETEthernet.Config	{...}
[-] MVI56EMNETEthernet.Config.IP	{...}
+ MVI56EMNETEthernet.Config.IP[0]	105
+ MVI56EMNETEthernet.Config.IP[1]	102
+ MVI56EMNETEthernet.Config.IP[2]	0
+ MVI56EMNETEthernet.Config.IP[3]	12
[-] MVI56EMNETEthernet.Config.Netmask	{...}
+ MVI56EMNETEthernet.Config.Netmask[0]	255
+ MVI56EMNETEthernet.Config.Netmask[1]	255
+ MVI56EMNETEthernet.Config.Netmask[2]	255
+ MVI56EMNETEthernet.Config.Netmask[3]	0
[-] MVI56EMNETEthernet.Config.Gateway	{...}
+ MVI56EMNETEthernet.Config.Gateway[0]	192
+ MVI56EMNETEthernet.Config.Gateway[1]	168
+ MVI56EMNETEthernet.Config.Gateway[2]	0
+ MVI56EMNETEthernet.Config.Gateway[3]	1

To check the status of the message, refer to the *WriteEthernetMSG* tag.

[-] WriteEthernetMSG	{...}
+ WriteEthernetMSG.Flags	16#0200
- WriteEthernetMSG.EW	0
- WriteEthernetMSG.ER	0
- WriteEthernetMSG.DN	0
- WriteEthernetMSG.ST	0
- WriteEthernetMSG.EN	0
- WriteEthernetMSG.TO	0
- WriteEthernetMSG.EN_CC	1
+ WriteEthernetMSG.ERR	16#0000
+ WriteEthernetMSG.EXERR	16#0000_0000
+ WriteEthernetMSG.ERR_SRC	0
+ WriteEthernetMSG.DN_LEN	0
+ WriteEthernetMSG.REQ_LEN	24

### 5.6.6 Reading the Clock Value from the Module

Expand the *MVI56MNETClock* controller tag and move a value of 1 to *MVI56MNETClock.Read*.

[-] MVI56MNETClock	{...}
[-] MVI56MNETClock.Read	1
[-] MVI56MNETClock.Write	0
[-] MVI56MNETClock.Config	{...}
[-] MVI56MNETClock.Config.Year	0
[-] MVI56MNETClock.Config.Month	0
[-] MVI56MNETClock.Config.Day	0
[-] MVI56MNETClock.Config.Hour	0
[-] MVI56MNETClock.Config.Minute	0
[-] MVI56MNETClock.Config.Seconds	0

The bit will be automatically reset and the current clock value will be copied to *MVI56MNETClock.Config* controller tag as follows.

[-] MVI56MNETClock	{...}
[-] MVI56MNETClock.Read	0
[-] MVI56MNETClock.Write	0
[-] MVI56MNETClock.Config	{...}
[-] MVI56MNETClock.Config.Year	2009
[-] MVI56MNETClock.Config.Month	6
[-] MVI56MNETClock.Config.Day	18
[-] MVI56MNETClock.Config.Hour	10
[-] MVI56MNETClock.Config.Minute	44
[-] MVI56MNETClock.Config.Seconds	21

To check the status of the message, refer to the *ReadClockMSG* tag.

[-] ReadClockMSG	{...}
[-] ReadClockMSG.Flags	16#0200
[-] ReadClockMSG.EW	0
[-] ReadClockMSG.ER	0
[-] ReadClockMSG.DN	0
[-] ReadClockMSG.ST	0
[-] ReadClockMSG.EN	0
[-] ReadClockMSG.TO	0
[-] ReadClockMSG.EN_CC	1
[-] ReadClockMSG.ERR	16#0000
[-] ReadClockMSG.EXERR	16#0000_0000
[-] ReadClockMSG.ERR_SRC	0
[-] ReadClockMSG.DN_LEN	0
[-] ReadClockMSG.REQ_LEN	0

### 5.6.7 Writing the Clock Value to the Module

Expand the *MVI56MNETClock* controller tag.

Set the new Clock value in *MVI56MNETClock.Config*:

Move a value of 1 to *MVI56MNETClock.Write*.

[-] MVI56MNETClock	{...}
[-] MVI56MNETClock.Read	0
[-] MVI56MNETClock.Write	1
[-] MVI56MNETClock.Config	{...}
+ MVI56MNETClock.Config.Year	2009
+ MVI56MNETClock.Config.Month	6
+ MVI56MNETClock.Config.Day	18
+ MVI56MNETClock.Config.Hour	10
+ MVI56MNETClock.Config.Minute	44
+ MVI56MNETClock.Config.Seconds	21

The bit will be automatically reset to 0.


[-] MVI56MNETClock	{...}
[-] MVI56MNETClock.Read	0
[-] MVI56MNETClock.Write	0
[-] MVI56MNETClock.Config	{...}
+ MVI56MNETClock.Config.Year	2009
+ MVI56MNETClock.Config.Month	6
+ MVI56MNETClock.Config.Day	18
+ MVI56MNETClock.Config.Hour	10
+ MVI56MNETClock.Config.Minute	44
+ MVI56MNETClock.Config.Seconds	21

To check the status of the message, refer to the *WriteClockMSG* tag.


[-] WriteClockMSG	{...}
+ WriteClockMSG.Flags	16#0200
[-] WriteClockMSG.EW	0
[-] WriteClockMSG.ER	0
[-] WriteClockMSG.DN	0
[-] WriteClockMSG.ST	0
[-] WriteClockMSG.EN	0
[-] WriteClockMSG.TO	0
[-] WriteClockMSG.EN_CC	1
+ WriteClockMSG.ERR	16#0000
+ WriteClockMSG.EXERR	16#0000_0000
+ WriteClockMSG.ERR_SRC	0
+ WriteClockMSG.DN_LEN	0
+ WriteClockMSG.REQ_LEN	24

## 5.7 Adding the Module to an Existing Project

- 1 Select the *I/O Configuration* folder in the *Controller Organization* window of RSLogix 5000, and then click the right mouse button to open a shortcut menu. On the shortcut menu, choose **NEW MODULE**.



This action opens the *Select Module* dialog box:




- 2 Select the **1756-MODULE (GENERIC 1756 MODULE)** from the list and click **OK**. This action opens the *New Module* dialog box.
- 3 Enter the *Name*, *Description* and *Slot* options for your application. You must select the *Comm Format* as **DATA - INT** in the dialog box, otherwise the module will not communicate. Click **OK** to continue.




Parameter	Value
Name	Enter a module identification string. Example: <b>MNET_2</b>
Description	Enter a description for the module. Example: <b>MODBUS TCP/IP INTERFACE MODULE</b>
Comm Format	Select <b>DATA-INT</b> .
Slot	Enter the slot number in the rack where the MVI56E-MNET module is located.
Input Assembly Instance	<b>1</b>
Input Size	<b>250</b>
Output Assembly Instance	<b>2</b>
Output Size	<b>248</b>
Configuration Assembly Instance	<b>4</b>
Configuration Size	<b>0</b>

- 4 Select the *Requested Packet Interval* value for scanning the I/O on the module. This value represents the minimum frequency that the module will handle scheduled events. This value should not be set to less than **1** millisecond. The default value is **5** milliseconds. Values between **1** and **10** milliseconds should work with most applications.



- 5 Save the module. Click **OK** to dismiss the dialog box. The *Controller Organization* window now displays the module's presence.



- 6 Copy the *User-Defined Data Types* from the sample program into your existing RSLogix 5000 project.
- 7 Copy the *Controller Tags* from the sample program into your project.
- 8 Copy the *Ladder Rungs* from the sample program into your project.

## 5.8 Using the Sample Program

If your processor uses RSLogix 5000 version 15 or earlier, you will not be able to use the Add-On Instruction for your module. Follow the steps below to obtain and use a sample program for your application.

### 5.8.1 Opening the Sample Program in RSLogix

The sample program for your MVI56E-MNET module includes custom tags, data types and ladder logic for data I/O, status and command control. For most applications, you can run the sample program without modification, or, for advanced applications, you can incorporate the sample program into your existing application.

#### **Download the manuals and sample program from the ProSoft Technology web site**

You can always download the latest version of the sample ladder logic and user manuals for the MVI56E-MNET module from the ProSoft Technology website, at [www.prosoft-technology.com/prosoft/support/downloads](http://www.prosoft-technology.com/prosoft/support/downloads) (<http://www.prosoft-technology.com/prosoft/support/downloads>)


From that link, navigate to the download page for your module and choose the sample program to download for your version of RSLogix 5000 and your processor.

#### **To determine the firmware version of your processor**


**Important:** The RSLinx service must be installed and running on your computer in order for RSLogix to communicate with the processor. Refer to your RSLinx and RSLogix documentation for help configuring and troubleshooting these applications.

- 1 Connect an RS-232 serial cable from the COM (serial) port on your PC to the communication port on the front of the processor.
- 2 Start RSLogix 5000 and close any existing project that may be loaded.
- 3 Open the **COMMUNICATIONS** menu and choose **GO ONLINE**. RSLogix will establish communication with the processor. This may take a few moments.

- 4 When RSLogix has established communication with the processor, the *Connected To Go Online* dialog box will open.



- 5 In the *Connected To Go Online* dialog box, click the **GENERAL** tab. This tab shows information about the processor, including the Revision (firmware) version. In the following illustration, the firmware version is 11.32



- 6 Select the sample ladder logic file for your firmware version.

**To open the sample program**


- 1 On the *Connected to Go Online* dialog box, click the **SELECT FILE** button.
- 2 Choose the sample program file that matches your firmware version, and then click the **SELECT** button.
- 3 RSLogix will load the sample program.

The next step is to configure the correct controller type and slot number for your application.


## 5.8.2 Choosing the Controller Type

The sample application is for a 1756-L63 ControlLogix 5563 Controller. If you are using a different model of the ControlLogix processor, you must configure the sample program to use the correct processor model.

- 1 In the *Controller Organization* list, select the folder for the controller and then click the right mouse button to open a shortcut menu.
- 2 On the shortcut menu, choose **PROPERTIES**. This action opens the *Controller Properties* dialog box.



- 3 Click the **CHANGE TYPE** or **CHANGE CONTROLLER** button. This action opens the *Change Controller* dialog box.




- 4 Open the **TYPE** dropdown list, and then select your ControlLogix controller.
- 5 Select the correct firmware revision for your controller, if necessary.
- 6 Click **OK** to save your changes and return to the previous window.

### 5.8.3 Selecting the Slot Number for the Module

The sample application is for a module installed in Slot 1 in a ControlLogix rack. The ladder logic uses the slot number to identify the module. If you are installing the module in a different slot, you must update the ladder logic so that program tags and variables are correct, and do not conflict with other modules in the rack.

#### To change the slot number

- 1 In the *Controller Organization* list, select the module, and then click the right mouse button to open a shortcut menu.
- 2 On the shortcut menu, choose **PROPERTIES**. This action opens the *Module Properties* dialog box.



- 3 In the **SLOT** field, use the up and down arrows on the right side of the field to select the slot number where the module will reside in the rack, and then click **OK**.


RSLogix will automatically apply the slot number change to all tags, variables and ladder logic rungs that use the MVI56E-MNET slot number for computation.

### 5.8.4 Downloading the Sample Program to the Processor


#### To download the sample program from RSLogix 5000 to the ControlLogix processor

**Note:** The key switch on the front of the ControlLogix module must be in the REM position.

- 1 If you are not already online to the processor, open the **COMMUNICATIONS** menu, and then choose **DOWNLOAD**. RSLogix will establish communication with the processor.
- 2 When communication is established, RSLogix will open a confirmation dialog box. Click the **DOWNLOAD** button to transfer the sample program to the processor.



- 3 RSLogix will compile the program and transfer it to the processor. This process may take a few minutes.
- 4 When the download is complete, RSLogix will open another confirmation dialog box. Click **OK** to switch the processor from PROGRAM mode to RUN mode.



**Note:** If you receive an error message during these steps, refer to your RSLogix documentation to interpret and correct the error.

### ***5.8.5 Adding the Sample Ladder to an Existing Application***

- 1** Copy the Controller Tags (page 76) from the sample program.
- 2** Copy the User-Defined Data Types (page 78) from the sample program.
- 3** Copy the Ladder Rungs from the sample program.
- 4** Save and Download (page 33, page 167) the new application to the controller and place the processor in RUN mode.



## 6 Support, Service & Warranty

### In This Chapter

- ❖ Contacting Technical Support ..... 169
- ❖ Return Material Authorization (RMA) Policies and Conditions..... 171
- ❖ LIMITED WARRANTY ..... 173

### Contacting Technical Support

ProSoft Technology, Inc. (ProSoft) is committed to providing the most efficient and effective support possible. Before calling, please gather the following information to assist in expediting this process:

- 1 Product Version Number
- 2 System architecture
- 3 Network details

If the issue is hardware related, we will also need information regarding:

- 1 Module configuration and associated ladder files, if any
- 2 Module operation and any unusual behavior
- 3 Configuration/Debug status information
- 4 LED patterns
- 5 Details about the serial, Ethernet or fieldbus devices interfaced to the module, if any.

**Note:** For technical support calls within the United States, ProSoft's 24/7 after-hours phone support is available for urgent plant-down issues. Detailed contact information for all our worldwide locations is available on the following page.

<b>Internet</b>	Web Site: <a href="http://www.prosoft-technology.com/support">www.prosoft-technology.com/support</a> E-mail address: <a href="mailto:support@prosoft-technology.com">support@prosoft-technology.com</a>
<b>Asia Pacific</b> (location in Malaysia)	Tel: +603.7724.2080, E-mail: <a href="mailto:asiapc@prosoft-technology.com">asiapc@prosoft-technology.com</a> Languages spoken include: Chinese, English
<b>Asia Pacific</b> (location in China)	Tel: +86.21.5187.7337 x888, E-mail: <a href="mailto:asiapc@prosoft-technology.com">asiapc@prosoft-technology.com</a> Languages spoken include: Chinese, English
<b>Europe</b> (location in Toulouse, France)	Tel: +33 (0) 5.34.36.87.20, E-mail: <a href="mailto:support.EMEA@prosoft-technology.com">support.EMEA@prosoft-technology.com</a> Languages spoken include: French, English
<b>Europe</b> (location in Dubai, UAE)	Tel: +971-4-214-6911, E-mail: <a href="mailto:mea@prosoft-technology.com">mea@prosoft-technology.com</a> Languages spoken include: English, Hindi
<b>North America</b> (location in California)	Tel: +1.661.716.5100, E-mail: <a href="mailto:support@prosoft-technology.com">support@prosoft-technology.com</a> Languages spoken include: English, Spanish
<b>Latin America</b> (Oficina Regional)	Tel: +1-281-2989109, E-Mail: <a href="mailto:latinam@prosoft-technology.com">latinam@prosoft-technology.com</a> Languages spoken include: Spanish, English
<b>Latin America</b> (location in Puebla, Mexico)	Tel: +52-222-3-99-6565, E-mail: <a href="mailto:soporte@prosoft-technology.com">soporte@prosoft-technology.com</a> Languages spoken include: Spanish
<b>Brasil</b> (location in Sao Paulo)	Tel: +55-11-5083-3776, E-mail: <a href="mailto:brasil@prosoft-technology.com">brasil@prosoft-technology.com</a> Languages spoken include: Portuguese, English

For complete details regarding ProSoft Technology's TERMS & CONDITIONS OF SALE, WARRANTY, SUPPORT, SERVICE AND RETURN MATERIAL AUTHORIZATION INSTRUCTIONS please see the documents on the Product DVD or go to [www.prosoft-technology.com/legal](http://www.prosoft-technology.com/legal)

Documentation is subject to change without notice.

## **6.1 Return Material Authorization (RMA) Policies and Conditions**

The following Return Material Authorization (RMA) Policies and Conditions (collectively, "RMA Policies") apply to any returned product. These RMA Policies are subject to change by ProSoft Technology, Inc., without notice. For warranty information, see Limited Warranty (page 173). In the event of any inconsistency between the RMA Policies and the Warranty, the Warranty shall govern.

### **6.1.1 Returning Any Product**

- a) In order to return a Product for repair, exchange, or otherwise, the Customer must obtain a Return Material Authorization (RMA) number from ProSoft Technology and comply with ProSoft Technology shipping instructions.
- b) In the event that the Customer experiences a problem with the Product for any reason, Customer should contact ProSoft Technical Support at one of the telephone numbers listed above (page 169). A Technical Support Engineer will request that you perform several tests in an attempt to isolate the problem. If after completing these tests, the Product is found to be the source of the problem, we will issue an RMA.
- c) All returned Products must be shipped freight prepaid, in the original shipping container or equivalent, to the location specified by ProSoft Technology, and be accompanied by proof of purchase and receipt date. The RMA number is to be prominently marked on the outside of the shipping box. Customer agrees to insure the Product or assume the risk of loss or damage in transit. Products shipped to ProSoft Technology using a shipment method other than that specified by ProSoft Technology, or shipped without an RMA number will be returned to the Customer, freight collect. Contact ProSoft Technical Support for further information.
- d) A 10% restocking fee applies to all warranty credit returns, whereby a Customer has an application change, ordered too many, does not need, etc. Returns for credit require that all accessory parts included in the original box (i.e.; antennas, cables) be returned. Failure to return these items will result in a deduction from the total credit due for each missing item.

### **6.1.2 Returning Units Under Warranty**

A Technical Support Engineer must approve the return of Product under ProSoft Technology's Warranty:

- a) A replacement module will be shipped and invoiced. A purchase order will be required.
- b) Credit for a product under warranty will be issued upon receipt of authorized product by ProSoft Technology at designated location referenced on the Return Material Authorization
  - i. If a defect is found and is determined to be customer generated, or if the defect is otherwise not covered by ProSoft Technology's warranty, there will be no credit given. Customer will be contacted and can request module be returned at their expense;
  - ii. If defect is customer generated and is repairable, customer can authorize ProSoft Technology to repair the unit by providing a purchase order for 30% of the current list price plus freight charges, duties and taxes as applicable.

### **6.1.3 Returning Units Out of Warranty**

- a) Customer sends unit in for evaluation to location specified by ProSoft Technology, freight prepaid.
- b) If no defect is found, Customer will be charged the equivalent of \$100 USD, plus freight charges, duties and taxes as applicable. A new purchase order will be required.
- c) If unit is repaired, charge to Customer will be 30% of current list price (USD) plus freight charges, duties and taxes as applicable. A new purchase order will be required or authorization to use the purchase order submitted for evaluation fee.

**The following is a list of non-repairable units:**

- 3150 - All
- 3750
- 3600 - All
- 3700
- 3170 - All
- 3250
- 1560 - Can be repaired, only if defect is the power supply
- 1550 - Can be repaired, only if defect is the power supply
- 3350
- 3300
- 1500 - All

## 6.2 LIMITED WARRANTY

This Limited Warranty ("Warranty") governs all sales of hardware, software, and other products (collectively, "Product") manufactured and/or offered for sale by ProSoft Technology, Incorporated (ProSoft), and all related services provided by ProSoft, including maintenance, repair, warranty exchange, and service programs (collectively, "Services"). By purchasing or using the Product or Services, the individual or entity purchasing or using the Product or Services ("Customer") agrees to all of the terms and provisions (collectively, the "Terms") of this Limited Warranty. All sales of software or other intellectual property are, in addition, subject to any license agreement accompanying such software or other intellectual property.

### 6.2.1 What Is Covered By This Warranty

- a) *Warranty On New Products:* ProSoft warrants, to the original purchaser, that the Product that is the subject of the sale will (1) conform to and perform in accordance with published specifications prepared, approved and issued by ProSoft, and (2) will be free from defects in material or workmanship; provided these warranties only cover Product that is sold as new. This Warranty expires three (3) years from the date of shipment for Product purchased **on or after** January 1st, 2008, or one (1) year from the date of shipment for Product purchased **before** January 1st, 2008 (the "Warranty Period"). If the Customer discovers within the Warranty Period a failure of the Product to conform to specifications, or a defect in material or workmanship of the Product, the Customer must promptly notify ProSoft by fax, email or telephone. In no event may that notification be received by ProSoft later than 39 months from date of original shipment. Within a reasonable time after notification, ProSoft will correct any failure of the Product to conform to specifications or any defect in material or workmanship of the Product, with either new or remanufactured replacement parts. ProSoft reserves the right, and at its sole discretion, may replace unrepairable units with new or remanufactured equipment. All replacement units will be covered under warranty for the 3 year period commencing from the date of original equipment purchase, not the date of shipment of the replacement unit. Such repair, including both parts and labor, will be performed at ProSoft's expense. All warranty service will be performed at service centers designated by ProSoft.
- b) *Warranty On Services:* Materials and labor performed by ProSoft to repair a verified malfunction or defect are warranted in the terms specified above for new Product, provided said warranty will be for the period remaining on the original new equipment warranty or, if the original warranty is no longer in effect, for a period of 90 days from the date of repair.

### **6.2.2 What Is Not Covered By This Warranty**

- a) ProSoft makes no representation or warranty, expressed or implied, that the operation of software purchased from ProSoft will be uninterrupted or error free or that the functions contained in the software will meet or satisfy the purchaser's intended use or requirements; the Customer assumes complete responsibility for decisions made or actions taken based on information obtained using ProSoft software.
- b) This Warranty does not cover the failure of the Product to perform specified functions, or any other non-conformance, defects, losses or damages caused by or attributable to any of the following: (i) shipping; (ii) improper installation or other failure of Customer to adhere to ProSoft's specifications or instructions; (iii) unauthorized repair or maintenance; (iv) attachments, equipment, options, parts, software, or user-created programming (including, but not limited to, programs developed with any IEC 61131-3, "C" or any variant of "C" programming languages) not furnished by ProSoft; (v) use of the Product for purposes other than those for which it was designed; (vi) any other abuse, misapplication, neglect or misuse by the Customer; (vii) accident, improper testing or causes external to the Product such as, but not limited to, exposure to extremes of temperature or humidity, power failure or power surges; or (viii) disasters such as fire, flood, earthquake, wind and lightning.
- c) The information in this Agreement is subject to change without notice. ProSoft shall not be liable for technical or editorial errors or omissions made herein; nor for incidental or consequential damages resulting from the furnishing, performance or use of this material. The user guide included with your original product purchase from ProSoft contains information protected by copyright. No part of the guide may be duplicated or reproduced in any form without prior written consent from ProSoft.

### **6.2.3 Disclaimer Regarding High Risk Activities**

Product manufactured or supplied by ProSoft is not fault tolerant and is not designed, manufactured or intended for use in hazardous environments requiring fail-safe performance including and without limitation: the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines or weapons systems in which the failure of the product could lead directly or indirectly to death, personal injury or severe physical or environmental damage (collectively, "high risk activities"). ProSoft specifically disclaims any express or implied warranty of fitness for high risk activities.

#### **6.2.4 Intellectual Property Indemnity**

Buyer shall indemnify and hold harmless ProSoft and its employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim, investigation, litigation or proceeding (whether or not ProSoft is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Products. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless ProSoft and defend or settle any action brought against such Companies to the extent based on a claim that any Product made to Buyer specifications infringed intellectual property rights of another party. ProSoft makes no warranty that the product is or will be delivered free of any person's claiming of patent, trademark, or similar infringement. The Buyer assumes all risks (including the risk of suit) that the product or any use of the product will infringe existing or subsequently issued patents, trademarks, or copyrights.

- a) Any documentation included with Product purchased from ProSoft is protected by copyright and may not be duplicated or reproduced in any form without prior written consent from ProSoft.
- b) ProSoft's technical specifications and documentation that are included with the Product are subject to editing and modification without notice.
- c) Transfer of title shall not operate to convey to Customer any right to make, or have made, any Product supplied by ProSoft.
- d) Customer is granted no right or license to use any software or other intellectual property in any manner or for any purpose not expressly permitted by any license agreement accompanying such software or other intellectual property.
- e) Customer agrees that it shall not, and shall not authorize others to, copy software provided by ProSoft (except as expressly permitted in any license agreement accompanying such software); transfer software to a third party separately from the Product; modify, alter, translate, decode, decompile, disassemble, reverse-engineer or otherwise attempt to derive the source code of the software or create derivative works based on the software; export the software or underlying technology in contravention of applicable US and international export laws and regulations; or use the software other than as authorized in connection with use of Product.
- f) **Additional Restrictions Relating To Software And Other Intellectual Property**

In addition to compliance with the Terms of this Warranty, Customers purchasing software or other intellectual property shall comply with any license agreement accompanying such software or other intellectual property. Failure to do so may void this Warranty with respect to such software and/or other intellectual property.

#### **6.2.5 Disclaimer of all Other Warranties**

The Warranty set forth in What Is Covered By This Warranty (page 173) are in lieu of all other warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

### **6.2.6 Limitation of Remedies \*\***

In no event will ProSoft or its Dealer be liable for any special, incidental or consequential damages based on breach of warranty, breach of contract, negligence, strict tort or any other legal theory. Damages that ProSoft or its Dealer will not be responsible for include, but are not limited to: Loss of profits; loss of savings or revenue; loss of use of the product or any associated equipment; loss of data; cost of capital; cost of any substitute equipment, facilities, or services; downtime; the claims of third parties including, customers of the Purchaser; and, injury to property.

\*\* Some areas do not allow time limitations on an implied warranty, or allow the exclusion or limitation of incidental or consequential damages. In such areas, the above limitations may not apply. This Warranty gives you specific legal rights, and you may also have other rights which vary from place to place.

### **6.2.7 Time Limit for Bringing Suit**

Any action for breach of warranty must be commenced within 39 months following shipment of the Product.

### **6.2.8 No Other Warranties**

Unless modified in writing and signed by both parties, this Warranty is understood to be the complete and exclusive agreement between the parties, suspending all oral or written prior agreements and all other communications between the parties relating to the subject matter of this Warranty, including statements made by salesperson. No employee of ProSoft or any other party is authorized to make any warranty in addition to those made in this Warranty. The Customer is warned, therefore, to check this Warranty carefully to see that it correctly reflects those terms that are important to the Customer.

### **6.2.9 Allocation of Risks**

This Warranty allocates the risk of product failure between ProSoft and the Customer. This allocation is recognized by both parties and is reflected in the price of the goods. The Customer acknowledges that it has read this Warranty, understands it, and is bound by its Terms.



### ***6.2.10 Controlling Law and Severability***

This Warranty shall be governed by and construed in accordance with the laws of the United States and the domestic laws of the State of California, without reference to its conflicts of law provisions. If for any reason a court of competent jurisdiction finds any provisions of this Warranty, or a portion thereof, to be unenforceable, that provision shall be enforced to the maximum extent permissible and the remainder of this Warranty shall remain in full force and effect. Any cause of action with respect to the Product or Services must be instituted in a court of competent jurisdiction in the State of California.



# Index

## O

00 Return Query Data • 145

## A

About the MODBUS TCP/IP Protocol • 138  
Adding Multiple Modules (Optional) • 25  
Adding the Module to an Existing Project • 160  
Adding the Sample Ladder to an Existing Application • 168  
Adjusting the Input and Output Array Sizes • 30  
Allocation of Risks • 176  
ARP Timeout • 46

## B

Backplane Data Transfer • 110  
Backplane Error/Status Pointer • 42, 101  
Backplane Status • 97  
Battery Life Advisory • 4  
Before You Begin • 151  
Bit Input Offset • 55

## C

Choosing the Controller Type • 165  
Clearing a Fault Condition • 91  
Client Command Errors • 105, 135  
Client Command List • 135  
Client Driver • 134  
Client Error/Status Pointer • 44, 101  
Cold Boot Block (9999) • 130  
Command Control Blocks (5001 to 5006) • 123  
Command Entry Formats • 48  
Command Error Delay • 46  
Command Error Pointer • 45, 101  
Command List • 98  
Command List Entry Errors • 106  
Command List Overview • 47  
Command Status • 98  
Commands Supported by the Module • 48  
Comment • 53  
Config • 97, 98, 99  
Configuration Error Word • 83, 104  
Configuring Module Parameters • 40  
Configuring the MVI56E-MNET Module • 35  
Connecting to the Module's Web Page • 95  
Connecting Your PC to the ControlLogix Processor • 32  
Connecting Your PC to the Module • 59  
Connection Timeout • 56  
Contacting Technical Support • 169, 171  
Controller Tag Overview • 80  
Controller Tags • 76, 168

Controlling Law and Severability • 177  
Creating a New RSLogix 5000 Project • 19  
Creating Optional Comment Entries • 41  
Creating the Module • 20

## D

Data Flow between the MVI56E-MNET Module and ControlLogix Processor • 131  
Diagnostics (Function Code 08) • 145  
Diagnostics and Troubleshooting • 9, 87, 89  
Disclaimer of all Other Warranties • 175  
Disclaimer Regarding High Risk Activities • 174  
Downloading the Project to the Module • 31, 63  
Downloading the Sample Program to the Processor • 33, 167, 168  
Duplex/Speed Code • 44

## E

Enable • 49  
Ethernet Cable Configuration • 136  
Ethernet Cable Specifications • 136  
Ethernet Configuration • 58, 61  
Ethernet LED Indicators • 89  
Ethernet Performance • 137  
Event Command Blocks (2000) • 120  
Example 1  
    Local Rack Application • 66  
Example 2  
    Remote Rack Application • 69  
Example and State Diagram • 145

## F

Failure Flag Count • 43  
Float Flag • 45, 54  
Float Offset • 46, 55  
Float Start • 46, 55  
Force Multiple Coils (Function Code 15) • 147  
Force Single Coil (Function Code 05) • 143

## G

General Specifications • 108  
Get Module IP Address Block (9991) • 129  
Guide to the MVI56E-MNET User Manual • 9

## H

Hardware MAC Address • 57  
Hardware Specifications • 109  
Holding Register Offset • 56  
How to Contact Us • 2

## I

Importing the Add-On Instruction • 22  
Importing the Sample Add-On Instruction • 18, 23  
Initialize Output Data • 43  
Initialize Output Data Blocks (1000 to 1024) • 119  
Installing ProSoft Configuration Builder • 35  
Installing the Module in the Rack • 16

Installing the Rung Import with Optional Add-On  
Instruction • 152  
Intellectual Property Indemnity • 175  
Internal Address • 50  
IP Address • 57

## L

Ladder Logic • 75  
LED Status Indicators • 88  
Limitation of Remedies \*\* • 176  
LIMITED WARRANTY • 171, 173

## M

Markings • 3  
MB Address in Device • 53  
Minimum Command Delay • 45  
MNET Client Specific Errors • 106  
MNET Client x • 44  
MNET Client x Commands • 47, 120, 123  
MNET Servers • 54, 99  
MNET.CONTROL • 84  
MNET.DATA • 80  
MNET.STATUS • 83  
MNET.UTIL • 85  
Modbus Exception Codes • 150  
Modbus Exception Responses • 149  
Modbus Function • 52  
Modbus Protocol Specification • 138  
Modbus TCP/IP Specifications • 108  
Module • 42  
Module Communication Error Codes • 105  
Monitoring Backplane Information • 97  
Monitoring Database Information • 100  
Monitoring MNET Client Information • 98  
Monitoring MNET Server Information • 99  
Monitoring Module Information • 96  
MVI56(E)-MNET Controller Tags • 76  
MVI56(E)-MNET User-Defined Data Types • 78

## N

NIC Status • 97  
No Other Warranties • 176  
Node IP Address • 51, 52  
Non-Scrolling LED Status Indicators • 90  
Normal Data Transfer Blocks • 42, 44, 101, 113

## O

Opening the Sample Program in RSLogix • 163  
Output Offset • 55  
Overview • 151

## P

Package Contents • 14  
Pass-Through Blocks (9956-9961, 9970 and 9996) •  
126  
Pass-Through Mode • 44  
Pinouts • 108, 109, 136  
Poll Interval • 50

Preset Multiple Registers (Function Code 16) • 148  
Preset Single Register (Function Code 06) • 144  
Printing a Configuration File • 41  
Product Specifications • 9, 107  
ProSoft Technology® Product Documentation • 2

## R

Read Block • 113  
Read Coil Status (Function Code 01) • 139  
Read Holding Registers (Function Code 03) • 141  
Read Input Registers (Function Code 04) • 142  
Read Input Status (Function Code 02) • 140  
Read Register Count • 42, 81  
Read Register Start • 42  
Reading Status Data from the Module • 101  
Reading the Clock Value from the Module • 158  
Reading the Ethernet Settings from the Module • 156  
Reference • 9, 107  
Reg Count • 50  
Renaming an Object • 40  
Response Timeout • 45  
Retry Count • 45  
Return Material Authorization (RMA) Policies and  
Conditions • 171  
Returning Any Product • 171  
Returning Units Out of Warranty • 172  
Returning Units Under Warranty • 172

## S

Scrolling LED Status Indicators • 88  
Select Priority Read Block (Write Block Offset 247) •  
117  
Selecting the Slot Number for the Module • 166  
Server Driver • 132  
Service Port • 51  
Set Module IP Address Block (9990) • 129  
Setting Jumpers • 15  
Setting Module Parameters • 40  
Setting Up a Temporary IP Address • 60  
Setting Up the Project • 38  
Slave Address • 52  
Special Function Blocks • 85, 119  
Standard Modbus Exception Code Errors • 105  
Start Here • 9, 11  
Static ARP • 97  
Static ARP Table • 57, 97  
Status • 98, 99  
Status Data in Read Block • 83, 97, 101, 102, 114, 115  
Sub-function Codes Supported • 145  
Support, Service & Warranty • 9, 169  
Swap Code • 51  
System Requirements • 13

## T

The Diagnostics Menu • 81, 82, 96, 101  
Time Limit for Bringing Suit • 176  
Troubleshooting • 91

## U

Upgrading from MVI56-MNET in ProSoft Configuration  
Builder • 12, 36  
User-Defined Data Types (UDTs) • 78, 168  
Using CIPconnect to Connect to the Module • 63, 64,  
73, 93, 137  
Using Controller Tags • 79  
Using ProSoft Configuration Builder Software • 36  
Using RSWho to Connect to the Module • 63, 73  
Using the Diagnostics Menu in ProSoft Configuration  
Builder • 92  
Using the Optional Add-On Instruction Rung Import •  
151  
Using the Sample Program • 18, 163

## V

Version • 96

## W

Warm Boot Block (9998) • 130  
Warnings • 3  
What Is Covered By This Warranty • 173, 175  
What Is Not Covered By This Warranty • 174  
What's New? • 12  
Word Input Offset • 56  
Write Block • 116  
Write Register Count • 43, 82  
Write Register Start • 43  
Writing the Clock Value to the Module • 159  
Writing the Ethernet Settings to the Module • 157

## Y

Your Feedback Please • 2